



# 2013 WaveRunner **FZS**

### **OWNER'S/OPERATOR'S MANUAL**

▲ Read this manual carefully before operating this watercraft. YAMAHA MOTOR CO., LTD. F2C-F8199-74-E0



EJU37544

### **Declaration of Conformity for Personal Watercraft (PWC)** with the requirements of Directive 94/25/EC, as amended by Directive 2003/44/EC

Name of Engine Manufacturer: YAMAHA MOTOR CO., LTD.  Address: 2500 Shingai, Iwata, Shizuoka 438-8501, Japan									
Name of Authorised Representative: YAMAHA MOTOR EUROPE N.V.  Address: Koolhovenlaan 101, 1119 NC Schiphole-Rijk, The Netherlands									
Name of Notified Body for exhaust and noise emission assessment: Luxcontrol SA ID Number: 0882  Address: 1. avenue des Terres Rouges BP 349, Esch-sur-Alzette, L-4004. Luxembourg									
Name of Notified Body for exhaust and noise emission assessment: SNCH ID Number: 0499  Address: 11, route de Luxembourg BP 32, Sandweiler, L-5230. Luxembourg									
Conformity assessment module used: for construction: A \( \times \) Aa \( \times \) B+C \( \times \) B+D \( \times \) B+F \( \times \) G \( \times \) H \( \times \) for exhaust emissions: B+C \( \times \) B+D \( \times \) B+E \( \times \) B+F \( \times \) G \( \times \) H \( \times \)									
Other	Community Direct	ctives applied					Stand	dards	
$\boxtimes$	Directive 2004/10	8/EC relating to electro	magnet	ic compa	tibility	(EMC).		CISPR 12 EN 61000-6-2	
	Directive 2006/42	EC relating to Machine	ery.					211 0 1000 0 2	
DESCRIPTION OF CRAFT  Craft model Identification Number, starting from: US - YAMA100011213  Design Category: C⊠D   Model name / Commercial name: GX1800A-M / FZS  DESCRIPTION OF ENGINE									
Engir	пе Туре:		Fuel Type:				Combustion cycle:		
				Petrol				4 stroke	
IDENTIFICATION OF ENGINE COVERED BY THIS DECLARATION OF CONFORMITY									
Name of engine model   EC Type-examination certificate number   Name / ID number of Notified Body					mber of Notified Body				
6AN LC*2003/44*10026			Luxcon			Luxcon	trol SA / 0882		
ESSENTIAL REQUIREMENTS									
Essential requirements standards			other normative document / method te		techr	technical file		Please specify in more detail (* = mandatory standard)	
_	sign and construction						EN ISO 13590		
I.B exhaust emission							*EN ISO 8178-1		
I.C noise emission									
This declaration of conformity is issued under the sole responsibility of the PWC manufacturer. I declare on behalf of the PWC manufacturer that the craft model and engine(s) mentioned above complies (comply) with all applicable essentia									

requirements in the way specified and is (are) in conformity with the type(s) for which above mentioned EC type-examination certificate(s) has (have) been issued.

Name / Title: H. Yamaji / President of YAMAHA MOTOR EUROPE N.V.

(identification of the person empowered to sign on behalf of the engine manufacturer or his authorised representative)

Signature and title: (or an equivalent marking)

Date and place of issue: 1st / September / 2012, Schiphol-Rijk, The Netherlands

### Important manual information

FJU30192

### To the owner/operator

Thank you for choosing a Yamaha watercraft. This owner's/operator's manual contains information you will need for proper operation, maintenance, and care. If you have any questions about the operation or maintenance of your watercraft, please consult a Yamaha dealer.

This manual is not a course on boating safety or seamanship. If this is your first watercraft, or if you are changing to a type of watercraft you are not familiar with, for your own comfort and safety, please ensure that you obtain proper training or practice before operating the watercraft by yourself. In addition, a Yamaha dealer or boating organization will be pleased to recommend local sea schools, or competent instructors.

In this manual, information of particular importance is distinguished in the following ways:

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

EWJ00071

### WARNING

A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

ECJ00091

### NOTICE

A NOTICE indicates special precautions that must be taken to avoid damage to the watercraft or other property.

### TIP:

A TIP provides key information to make procedures easier or clearer.

FJU40410

Because Yamaha has a policy of continuing product improvement, this product may not be exactly as described in this owner's/operator's manual. Specifications are subject to change without notice.

This manual should be considered a permanent part of this watercraft and should remain with it even if the watercraft is subsequently sold.

EJU30232

WaveRunner FZS
OWNER'S/OPERATOR'S MANUAL
©2012 by Yamaha Motor Co., Ltd.
1st Edition, July 2012
All rights reserved.
Any reprinting or unauthorized use without the written permission of Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in U.S.A.

### **Table of contents**

General and important labels1	Watercraft operation	32
Identification numbers 1	Watercraft operation functions	
Primary Identification (PRI-ID)	Reverse system	
number 1	Quick Shift Trim System	
Craft Identification Number (CIN) 1	(Q.S.T.S.)	33
Engine serial number 1	Watercraft operation modes	34
Manufactured date label 2	Low RPM Mode	34
Model information 2		
Builder's plate 2	Instrument operation	36
Important labels 4	Dual analog meter unit	
Warning labels 5	Speedometer	
Other labels9	Tachometer	
	Information display	
Safety information11		
Limitations on who may operate	Equipment operation	41
the watercraft	Equipment	
Cruising limitations	Seats	
	Handgrips	
Operation requirements	Reboarding grip	
Recommended equipment 15	Reboarding step	
Hazard information	Bow eye	
Watercraft characteristics 16	Stern eyes	
Water-skiing 18	Cleat	
Safe boating rules 19	Storage compartments	
Enjoy your watercraft	Fire extinguisher holder and	
responsibly 20	cover	47
Description21	Operation and handling	
Watercraft glossary 21	requirements	49
Location of main components 22	Fuel requirements	
•	Fuel	
Control function operation26	Engine oil requirements	
Watercraft control functions 26	Engine oil	
Remote control transmitter 26	Draining the bilge water	
Yamaha Security System 27	Draining the bilge water on land	
Engine stop switch 28	Draining the bilge water on water .	
Engine shut-off switch 28	Transporting on a trailer	
Start switch 28		
Throttle lever	First-time operation	55
Steering system 29	Engine break-in	
Telescopic steering system 30	Lingino broak in	
Cooling water pilot outlets 30	Pre-operation checks	E 4
Water separator 31	Pre-operation checklist	
	ו וכיטף כומנוטוו לוופלאווטנ	U

### **Table of contents**

Pre-operation check points	58	Periodic maintenance chart	86
Pre-launch checks		Engine oil and oil filter	87
Post-launch checks	65		
		Specifications	88
Operation	66	Specifications	88
Operating your watercraft	66		
Getting to know your watercraft	66	Trouble recovery	89
Learning to operate your		Troubleshooting	
watercraft	66	Troubleshooting chart	
Riding position		Emergency procedures	
Launching the watercraft		Cleaning the jet intake and	
Starting the engine on water		impeller	92
Stopping the engine		Jumping the battery	
Leaving the watercraft		Replacing the fuses	
Operating the watercraft		Replacing the bilge pump fuse	95
Turning the watercraft		Towing the watercraft	96
Stopping the watercraft	70	Submerged watercraft	97
Operating the watercraft in			
reverse			
Boarding the watercraft			
Starting off			
Capsized watercraft	75		
Beaching and docking the watercraft	76		
Operating in weeded areas	_		
After removing the watercraft from	//		
the water	77		
tile water	,,		
Care and storage	78		
Post-operation care			
Flushing the cooling water	70		
passages	78		
Cleaning the watercraft			
Battery care			
Long-term storage			
Cleaning			
Lubrication			
Rustproofing	-		
	-		
Maintenance	84		
Maintenance			
Tool kit			
Removing and installing the engine			
cover	8/		

F.II.I36451

### Identification numbers

Record the Primary Identification (PRI-ID) number, Craft Identification Number (CIN), and engine serial number in the spaces provided for assistance when ordering spare parts from a Yamaha dealer. Also record and keep these ID numbers in a separate place in case your watercraft is stolen.

EJU41350


### Primary Identification (PRI-ID) number

The PRI-ID number is stamped on a plate attached inside the engine compartment. (See page 41 for seat removal and installation procedures and page 46 for information on the watertight storage compartment.)

#### MODEL:

GX1800A-M (FZS)

|F|2|C|-|



Primary Identification (PRI-ID) number location

MODEL	F2C	
YAMAHA MOTOR CO., LTD. ASSEMBLED IN U.S.A. FROM A COMPONENTS. ASSEMBLÉ AUX ÉTATS-UNIS JAPONAISES.		



### **Craft Identification Number (CIN)**

The CIN is stamped on a plate attached to the aft deck.




1 Craft Identification Number (CIN) location



F.IU40470

#### **Engine serial number**

The engine serial number is stamped on a plate attached to the engine unit. (See page 41 for seat removal and installation procedures and page 84 for engine cover removal and installation procedures.)




1 Engine serial number location



FJU42030

#### Manufactured date label

This label is attached to the top of the cylinder head. (See page 41 for seat removal and installation procedures and page 84 for engine cover removal and installation procedures.)



1 Manufactured date label location



EJU30320


#### Model information

EJU30331


#### Builder's plate

Watercraft with this label conform to certain portions of the European Parliament directive relating to machinery.

Part of the information is given on the builder's plate affixed on the craft. A full explanation of this information is given in the relevant sections of this manual.



1 Builder's plate location



Design category of this personal watercraft: C

### Category C:

This watercraft is designed to operate in winds up to Beaufort force 6 and the associated wave heights (significant wave heights up to 2 m (6.56 ft); see the following TIP). Such conditions may be encountered in exposed inland waters, in estuaries, and in coastal waters in moderate weather conditions.


### TIP:

The significant wave height is the mean height of the highest one-third of the waves, which approximately corresponds to the wave height estimated by an experienced observer. However, some waves will be double this height.

EJU30452

### **Important labels**


Read the following labels before using this watercraft. If have any questions, consult a Yamaha dealer.



EJU35913

### Warning labels

If any of these labels are damaged or missing, contact a Yamaha dealer for replacements.



2

#### A AVERTISSEMENT

Afin de limiter les risques de BLESURES GRAVES, voire MORTELLES: PORTER UN GILET DE SAUVETAGE. Tout utilisateur doit porter un gilet de sauvetage homologué pour les scooters des mers. PORTER DES VÉTEMENTS PROTECTEURS. Le choc infligé par le partentation forcée d'eau dans les orifices corporels lors d'une chateu ou lors du contact aux et jet d'eau de la pome risque de provoquer des lésions graves. Le port du militation ment de constitue pas une protection adéquate contre la puissance de pérdération de l'eau dans le rectum et/ou le tagin. Tou attitisateur doit porter le pantalon d'une constitue pas une protection adéquate contre la puissance de pérdération de l'eau dans le rectum et/ou le tagin. Tou attitisateur doit porter le pantalon d'une constitue pas une protection adéquate contre la puissance de pérdération de l'eau dans le rectum et/ou le tagin. Tou attitisateur doit porter le pantalon d'une constitue pas une protection admissille. (Voir le manuel d'utilisation.) Le port de chaussures, de gants et de unettes de plongée est recommande. CONVAÎTRE LES LOIS DE NAVIGATION. La Yamaha Motor Co., Ld. recommande la limite d'âge de pilotage de 16 ans. Verifier l'âge de pilota citis que le eagences quant et d'une partie de l'aux de la l'aux de l'aux se coupe bien en cas de chute. Après utilisation, retirer la lanière du scooter afin de prévenir toute utilisation par des enfants ou des personnes non-autorisées.

F1B-U41B1-21

3

#### **AAVERTISSEMENT**

Afin de limiter les risques de BLESSURES GRAVES, voire MORTELLES:

RESPECTER SES LIMITES ET ÉVITER LES MANOEUVRES BRUTALES afin de limiter tout risque de perte de contrôle, d'éjection et de collision. Il s'agit d'un véhicule à hautes performances et pas d'un jouet. Des virées brusques ou le saut de sillages ou de vagues accroît le risque de blessures au dos, voire de paralysie, de blessures au visage et de fractures diverses. <u>Ne iamais sauter</u>

NE PAS DONNER DES GAZ LORSQUE QUELQU'UN SE TROUVE DERRIÈRE LE VÉHICULE: couber le moteur ou laisser tourner au ralenti. Fau et/ou déhris projetés par la pompe pourraient causer des blessures graves

NE PAS S'APPROCHER DE LA GRILLE D'ADMISSION lorsque le moteur tourne. Cheveux longs, vêtements amples ou lanières de gilet de sauvetage risquent d'être happés, ce qui pourrait provoquer des blessures, ou même une noyade.

NE IAMAIS PILOTER APRÈS AVOIR ABSORBÉ DE L'ALCOOL, DES DROGUES OU CERTAINS MÉDICAMENTS.

F1B-U41B1-31

LIRE ET RESPECTER LES INSTRUCTIONS DONNÉES

DANS LE MANUEL D'UTILISATION

4

#### **A AVERTISSEMENT**

Les collisions sont la cause principale des BLESSURES ET DÉCÈS d'utilisateurs de scooter des mers. POUR ÉVITER LES COLLISIONS: ÉTRE CONSTAMMENT à l'affût de personnes, d'objets et d'autres bateaux. Être conscient des ≈ conditions limitant sa visibilité ou celle des autres embarcations PILOTER AVEC PRUDENCE à des vitesses raisonnables et garder une distance de sécurité entre le scooter et toute personne, objet et embarcation Ne pas suivre une autre embarcation de trop près.

Ne pas se rapprocher d'autrui en vue de l'éclabousser.

 Éviter les virages brusques ou toute manoeuvre qui risque de mettre un autre pilote en danger ou qui l'empêche de pouvoir déterminer clairement la direction que l'on prend. • Éviter les endroits où flottent des objets et les eaux peu profondes. RÉAGIR RAPIDEMENT en vue d'éviter les collisions. Garder à l'esprit que les

bateaux <u>n'ont pas de freins.</u> NE PAS LÂCHER LES GAZ LORSQUE L'ON ESSAYE DE S'ÉLOIGNER

d'objets-une poussée est nécessaire à la direction du scooter des mers. Toujours s'assurer avant le départ que l'accélérateur et la direction fonctionnent correctement. Suivre les lois de navigation ainsi que les législations nationales YAMAHA provinciales et locales concernant les scooters des mers. Voir le manuel d'utilisation pour plus d'informations.

F1B-U41B2-01

5

#### **AWARNING**

Gasoline is highly flammable and explosive. A fire or explosion could cause severe injury or death. Shut engine off. Refuel in well ventilated area away from flames or sparks. Bo not smoke. Avoid spiffing gasoline. Wipe up spifled gasoline immediately.

Remove all seats to ventilate fuel vapors from engine compartment before starting engine. Do not start engine if there is a fuel leak or a loose electrical connection.

### **A AVERTISSEMENT**

L'essence est très inflammable et explosible. Un incendie ou une explosion risquent de provoquer des blessures graves, voire mortelles. Couper le moteur. Faire le plein dans un endroit bien aéré et éloigné de toute flamme ou étincelle. Ne pas famer. Éviter des rennerser de l'essence. Essuyer immédiatement toute coulure d'essence. Déposer les selles pour évacuer les voluers d'essence du compartiment du moteur avant de mettre le moteur en marche. Ne jamais mettre le moteur en marche en cas de fuite d'essence ou si un branchement électrique est desserré.

REGULAR UNLEADED GASOLINE ONLY

ESSENCE NORMALE SANS PLOMB UNIQUEMENT

F1S-U415B-1

6

#### **AWARNING**

#### REVERSE SHIFT LEVER OPERATION:

- Shift only while engine is idling or off.
- Reverse is for low speed maneuvering only.
- Do not use reverse function to slow down or stop PWC as it could cause you to lose control, be ejected, or impact handlebars.
- Make sure that there are no obstacles or people behind you before shifting to reverse.

#### **AAVERTISSEMENT**

#### FONCTIONNEMENT DU LEVIER D'INVERSION DE MARCHE:

- •Inverser la marche uniquement lorsque le moteur tourne au ralenti ou lorsqu'il est coupé.
- •La marche arrière est destinée exclusivement aux manœuvres à vitesse réduite.
- Ne pas sélectionner la marche arrière en vue de ralentir ou d'arrêter le scooter des mers, car il y a risque de perte de contrôle, d'éjection ou de heurt sur le guidon.
- S'assurer qu'il n'y a ni obstacle ni personne derrière le scooter avant d'engager la marche arrière.

F0V-U41D5-31

•

### **AWARNING**

Do not use cleat or grips to lift PWC. PWC could fall, which could result in severe injury.

#### **A**AVERTISSEMENT

Ne pas soulever le scooter à l'aide du taquet ou des poignées. Le scooter pourrait tomber et provoquer des blessures graves.

(F1S-U41E1-11)

8

### **AWARNING**


- Severe internal injuries can occur if water is forced into body cavities as a result
  of being near jet thrust nozzle.
- •Wear a wetsuit bottom or clothing that provides equivalent protection.
- Do not board PWC if operator is applying throttle.

#### **AAVERTISSEMENT**

- Le choc infligé par la pénétration forcée d'eau dans les orifices corporels lors du contact avec le jet de le pompe risque de provoquer des lésions graves.
- Porter le pantaion d'une tenue de plongée ou tout autre vêtement offrant une protection semblable.
- •Ne pas embarquer lorsque la pilote donne des gaz.

(F1S-U41E1-11)

9



10

### **▲** AVERTISSEMENT

APPLICABLE POUR LA FRANCE SEULEMENT

• En France : pèrmis de conduire et immatriculation obligatoire.
• Navigation en mer autorisée entre 300 mètres et 2 milles nautique.
• Entre 0 et 300 mètres, se réferer aux instructions nautiques locales affichées. Sinon, règle générale : vitesse maxi 5 noeuds (9Km/h) dans cette zone.
• Utiliser les chenaux obligatoires de sortie lorsqu'ils existent.
• Respecter les règles de priorité.
• Gilet de sauvetage obligatoire-Fusée et bout de remorquage à bord.
• Ne jamais conduire sous l'influence de l'alcool ou de drogues.
• Consulter la météo avant de sortir en mer.
• Une conduite restonsable et un contrôle quotidien de votre machine suivant le manuel.

Une conduite responsable et un contrôle quotidien de votre machine suivant le manuel d'entretien YAMAHA seront garants de votre sécurité.

EJU36261

#### Other labels

11

# FIRE EXTINGUISHER CONTAINER COMPARTIMENT DE L'EXTINCTEUR

F1B-U41F5-21

12

RATED PERSON CAPACITY: 3 Maximum Load: 240 kg (530 lb) Capacité Maximale: 3 personnes Charge Maximale: 240 kg(530 lb)

(F1S-U41E1-11)




The following label indicates the correct direction to upright a capsized watercraft.

### 14



The following CE marking is located on the back of the remote control transmitter.





EJU30682

The safe use and operation of this watercraft is dependent upon the use of proper riding techniques, as well as upon the common sense, good judgment, and expertise of the operator. Before using this watercraft, make sure that its use is permitted under local laws, bylaws, and regulations, and always operate the watercraft in full conformity with any requirements and limitations imposed. Every operator should know the following requirements before riding the watercraft.

- Before operating the watercraft, read this owner's/operator's manual, the Riding Practice Guide, the Riding Instruction card, and all labels on the watercraft. These materials should give you an understanding of the watercraft and its operation.
- Never allow anyone to operate this watercraft until they too have read this owner's/operator's manual, the Riding Practice Guide, the Riding Instruction card, and all labels.

FJU30740

# Limitations on who may operate the watercraft

- Yamaha recommends a minimum operator age of 16 years old.
  - Adults must supervise use by minors. Know your local operator age and training requirements.
- This watercraft is designed to carry the operator and up to 2 passengers. Never exceed the maximum load limit or allow more than 3 persons (or 2 persons if a water-skier is being pulled) to ride the watercraft at any time.



Maximum load: 240 kg (530 lb) Load is the total weight of cargo, operator, and passengers.


Do not operate the watercraft with any passengers on board until you have considerable practice and experience riding alone.
 Operating the watercraft with passengers requires more skill. Take the time to become accustomed to the handling characteristics of the watercraft before trying any difficult maneuvers.

### **⚠** Safety information

FJU30761


### **Cruising limitations**

 Scan constantly for people, objects, and other watercraft. Be alert for conditions that limit your visibility or block your vision of others.



- Operate defensively at safe speeds and keep a safe distance away from people, objects, and other watercraft.
- Do not follow directly behind watercraft or other boats.
- Do not go near others to spray or splash them with water.
- Avoid sharp turns or other maneuvers that make it hard for others to avoid you or understand where you are going.
- Avoid areas with submerged objects or shallow water.
- Take early action to avoid collisions. Remember, watercraft and other boats do not have brakes.
- Do not release the throttle lever when trying to steer away from objects—you need throttle to steer. Always check throttle and steering controls before starting the watercraft.
- Ride within your limits and avoid aggressive maneuvers to reduce the risk of loss of control, ejection, and collision.
- This is a high performance boat—not a toy.
   Sharp turns or jumping wakes or waves can increase the risk of back/spinal injury (paralysis), facial injuries, and broken legs, an-


- kles, and other bones. Do not jump wakes or waves.
- Do not operate the watercraft in rough water, bad weather, or when visibility is poor; this may lead to an accident causing injury or death. Be alert to the possibility of adverse weather. Take note of weather forecasts and the prevailing weather conditions before setting out on your watercraft.
- As with any water sport, you should not operate your watercraft without someone else nearby. If you operate further than swimming distance from shore, you should be accompanied by another boat or watercraft, but make sure you stay a safe distance away. It's good, common sense.
- Never operate in water that is less than 60 cm (2 ft) deep from the bottom of the watercraft, otherwise you increase your chance of hitting a submerged object, which could result in injury.



 This watercraft is not equipped with lighting required for night operation. Do not operate the watercraft after sunset or before dawn, otherwise you increase the risk of colliding

### **⚠** Safety information

with another boat, which could result in severe injury or death.




Follow navigation rules, and state/provincial and local laws that apply to watercraft.

FJU30821

### **Operation requirements**

- All riders must wear a personal flotation device (PFD) that is approved by the appropriate authorities and is suitable for personal watercraft use.
- Wear protective clothing. Severe internal injuries can occur if water is forced into body cavities as a result of falling into the water or being near the jet thrust nozzle. Normal swimwear does not adequately protect against forceful water entry into the rectum or vagina. All riders must wear a wetsuit bottom or clothing that provides equivalent protection. Such clothing includes thick, tightly woven, sturdy and snug-fitting apparel such as denim, but does not include spandex or similar fabrics, like those used in bicycle shorts.



- 1 Authority-approved PFD
- 2 Wetsuit bottom
- Eye protection is recommended to keep wind, water, and glare from the sun out of your eyes while you operate your watercraft. Restraining straps for eyewear are made which are designed to float should your eyewear fall in the water.
  - Footwear and gloves are recommended.
- You must decide whether to wear a helmet while you ride for recreation. You should know that a helmet could help protect you in

### 

certain kinds of accidents and that it could injure you in others.

A helmet is designed to provide some head protection. Although helmets cannot protect against all foreseeable impacts, a helmet might reduce your injuries in a collision with a boat or other obstacle.

A helmet may have potential safety hazards, as well. Falling into the water could risk the chance of the helmet catching water, commonly known as "bucketing", and the resulting strain on your neck could cause choking, severe and permanent neck injuries, or death. A helmet could also increase the risk of an accident if it reduces your vision or hearing, or if it distracts you or increases your fatigue.

How should you decide if a helmet's potential safety benefits outweigh its potential risks for you? Consider your particular riding conditions. Consider factors such as your riding environment and your riding style and ability. Also consider the likelihood of traffic congestion, and the water surface conditions.

If you decide to wear a helmet based upon your riding circumstances, choose one carefully. Look for a helmet designed for personal watercraft use, if possible. If you will be engaging in closed-course competition, follow the helmet requirements of the sanctioning organization.

- Never operate the watercraft after consuming alcohol or taking other drugs.
- For reasons of safety and proper care of the watercraft, always perform the pre-operation checks listed on page 56 before operating the watercraft.
- The operator and passengers should always keep their feet on the floor of the footwell when the watercraft is in motion. Lifting

your feet increases the chances of losing your balance, or hitting objects outside the watercraft with your feet. Do not give a ride to children if their feet cannot reach the floor of the footwell.


 The passengers should hold on firmly, either to the person in front of them or to the handgrip provided.



- Never allow a passenger to ride in front of the operator.
- Always consult your doctor on whether it is safe for you to ride this watercraft if you are pregnant or in poor health.
- Do not attempt to modify this watercraft.
   Modifications to your watercraft may reduce safety and reliability, and render the watercraft unsafe or illegal for use.
- Attach the engine shut-off cord (lanyard) to your left wrist and keep it free from the handlebars so that the engine stops if you, the operator, fall off. After riding, remove the engine shut-off cord (lanyard) from the wa-

### **△ Safety information**

tercraft to avoid accidental starting or unauthorized use by children or others.



- Scan carefully for swimmers and stay away from swimming areas. Swimmers are hard to see and you could accidentally hit someone in the water.
- Avoid being hit by another boat. You should always take the responsibility to watch for traffic; other boaters may not be watching for you. If they do not see you, or if you maneuver more quickly than other boaters expect, you risk a collision.
- Maintain a safe distance from other boats and watercraft, and also watch for ski ropes or fishing lines. Obey the "Safe boating rules" and be sure to check behind you before making a turn. (See "Safe boating rules" on page 19.)

FJU30840

Towline

### Recommended equipment

The following items should be carried on board your watercraft:

- Sound-signaling device
   You should carry a whistle or other soundsignaling device that can be used to signal
   other boats.
- Visual distress signals
   It is recommended that a pyrotechnic device, which is approved by the appropriate authorities, be stored in a waterproof container on your watercraft. A mirror can also be used as an emergency signal. Contact a Yamaha dealer for more information.
- Watch
   A watch is helpful so you will know how long you have been operating the watercraft.
  - A towline can be used to tow a disabled watercraft in an emergency.

### 

FJU36850

### **Hazard information**

- Never start the engine or let it run for any length of time in an enclosed area. Exhaust fumes contain carbon monoxide, a colorless, odorless gas that may cause loss of consciousness and death within a short time. Always operate the watercraft in an open area.
- Do not touch the hot muffler or engine during or immediately after engine operation; they can cause serious burns.

F.II.I30920

### Watercraft characteristics

 Jet thrust turns the watercraft. Releasing the throttle lever completely produces only minimum thrust. If you are traveling at speeds above trolling, you will have rapidly decreasing ability to steer without throttle.

This model is equipped with the Yamaha Engine Management System (YEMS) that includes an off-throttle steering (OTS) system. It will activate at planing speeds should you attempt to steer the watercraft after releasing the throttle lever. The OTS system assists in turning by continuing to supply some thrust while the watercraft is decelerating, but you can turn more sharply if you apply throttle while turning the handlebars.

The OTS system does not function below planing speeds or when the engine is off. Once the engine slows down, the watercraft will no longer turn in response to handlebar input until you apply throttle again or you reach trolling speed.


Practice turning in an open area without obstacles until you have a good feel for this maneuver.

- This watercraft is water-jet propelled. The jet pump is directly connected to the engine.
   This means that jet thrust will produce some movement whenever the engine is running.
   There is no "neutral" position. You are in either "forward" or "reverse", depending upon the shift lever position.
- Do not use the reverse function to slow down or stop the watercraft as it could cause you to lose control, be ejected, or impact the handlebars.

This could increase the risk of back/spinal injury (paralysis), facial injuries, and broken legs, ankles, and other bones. You could also damage the shift mechanism.


### **△ Safety information**

- Reverse can be used to slow down or stop during slow-speed maneuvering, such as when docking. Once the engine is idling, shift into reverse and gradually increase engine speed. Make sure that there are no obstacles or people behind you before shifting into reverse.
- Keep away from the intake grate while the engine is on. Items such as long hair, loose clothing, or PFD straps can become entangled in moving parts, resulting in severe injury or drowning.
- Never insert any object into the jet thrust nozzle while the engine is running. Severe injury or death could result from coming in contact with the rotating parts of the jet pump.



- 1 Intake grate
- 2 Jet thrust nozzle
- Stop the engine and remove the clip from the engine shut-off switch before removing

any debris or weeds, which may have collected around the jet intake.



- 1 Clip
- 2 Engine shut-off switch


### Safety information

EJU30954

### Water-skiing

You can use the watercraft for water-skiing if it has the seating capacity to carry the operator, a rearward-facing spotter, and the water-skier when he or she is not skiing.

The watercraft must also have a cleat designed to pull a ski rope; do not attach the rope to any other location.



It is the watercraft operator's responsibility to be alert to the safety of the water-skier and others. Know and follow all local water-skiing regulations in effect for the waters in which you will be operating.

The operator should be comfortable carrying passengers before attempting to pull a skier. The following are some important considerations for minimizing risks while water-skiing.


- The skier should wear an approved PFD, preferably a brightly colored one so boat operators can see the skier.
- The skier should wear protective clothing. Severe internal injuries can occur if water is forced into body cavities as a result of falling into the water. Normal swimwear does not adequately protect against forceful water entry into the rectum or vagina. The skier should wear a wetsuit bottom or clothing that provides equivalent protection.
- A second person should be on board as a spotter to watch the skier; in many places it

is required by law. Let the skier direct the operator's control of speed and direction with hand signals.

The spotter should sit astride the rear of the seat and hold onto the handgrip with both feet firmly on the floor of the footwell for proper balance while facing to the rear to watch the skier's hand signals and condition.



#### 1 Handgrip



- Your control while pulling a water-skier is affected by the skier's ability, as well as water and weather conditions.
- When preparing to pull a skier, operate the watercraft at the slowest possible speed until the watercraft is well away from the skier and slack in the ski rope is taken up.

### **△ Safety information**

Make sure that the rope is not looped around anything.

After checking that the skier is ready and that there is no traffic or other obstacles, apply enough throttle to raise the skier.

- Make smooth, wide turns. The watercraft is capable of very sharp turns, which could exceed the abilities of the skier. Keep the skier at least 50 m (164 ft), about twice the distance of a standard ski rope, from any potential hazard.
- Be alert to the hazard of the ski rope handle snapping back at the watercraft when the skier falls or is unable to get up on the skis.
- Towing heavy or bulky objects other than skiers, such as another boat or watercraft, can cause loss of steering control and create a hazardous condition. If you must tow another boat in an emergency situation, operate slowly and cautiously.

EJU30970

### Safe boating rules

Your Yamaha watercraft is legally considered a powerboat. Operation of the watercraft must be in accordance with the rules and regulations governing the waterway on which it is used.

### **⚠** Safety information

EJU30991

## Enjoy your watercraft responsibly

You share the areas you enjoy when riding your watercraft with others and with nature. So your enjoyment includes a responsibility to treat these other people, and the lands, waters, and wildlife with respect and courtesy. Whenever and wherever you ride, think of yourself as the guest of those around you. Remember, for example, that the sound of your watercraft may be music to you, but it could be just noise to others. And the exciting splash of your wake can make waves others won't enjoy.

Avoid riding close to shoreline homes and waterfowl nesting areas or other wildlife areas, and keep a respectful distance from fishermen, other boats, swimmers, and populated beaches. When travel in areas like these is unavoidable, ride slowly and obey all laws.

Proper maintenance is necessary to ensure that the exhaust emission and sound levels of your watercraft will continue to be within regulated limits. You have the responsibility to make sure that the recommended maintenance in this owner's/operator's manual is carried out.

Remember, pollution can be harmful to the environment. Do not refuel or add oil where a spill could cause damage to nature. Remove your watercraft from the water and move it away from the shoreline before refueling. Dispose of water and any fuel and oil residue in the engine compartment according to local regulations. And keep your surroundings pleasant for the people and wildlife that share the waterways: don't litter.

When you ride responsibly, with respect and courtesy for others, you help ensure that our

waterways stay open for the enjoyment of a variety of recreational opportunities.

F.II I40302

### Watercraft glossary

### Trolling speed

"Trolling" is the lowest maneuvering speed. You are applying little or no throttle. The watercraft is down in the water, and there is no wake.

### Sub-planing speed

"Sub-planing" is a medium speed. The bow of the watercraft is slightly up from the water surface, but you are still traveling through the water. There is a wake.

### Planing speed

"Planing" is a faster speed. The watercraft is more level and is skimming on top of the water. There is a wake.

#### Bow

The front end of the watercraft.

#### Stern

The rear end of the watercraft.

#### Starboard

The right side of the watercraft when facing forward.

#### Port

The left side of the watercraft when facing forward.

#### Bilge water

Water that has collected in the engine compartment.

### Yamaha Engine Management System (YEMS)


YEMS is an integrated, computerized management system that controls and adjusts ignition timing, fuel injection, engine diagnostics, and the off-throttle steering (OTS) system.

### **Description**

EJU31011


### Location of main components

#### **Exterior**




- 1 Fuel filler cap (page 49)
- 2 Hood
- 3 Handlebars
- 4 Rear seat (page 41)
- 5 Front seat (page 41)
- 6 Footwell
- 7 Bow eye
- 8 Cooling water pilot outlet (page 30)
- 9 Gunwale
- 10 Sponson

### **Description**




- 2 Electric bilge pilot outlet
- 3 Reboarding grip (page 42)
- 4 Cleat
- 5 Handgrip (page 42)
- 6 Reboarding step (page 42)
- 7 Jet thrust nozzle
- 8 Reverse gate (page 32)
- 9 Ride plate
- 10 Stern drain plug (page 52)
- 11 Stern eye (page 43)
- 12 Speed sensor

### **Description**



- 1 Q.S.T.S. selector (page 33)
- 2 Q.S.T.S. selector lock lever (page 33)
- 3 Start switch (page 28)
- 4 Engine shut-off switch (page 28)
- 5 Clip (page 28)
- 6 Engine stop switch (page 28)
- 7 Engine shut-off cord (lanyard) (page 28)
- 8 Dual analog meter unit (page 36)
- 9 Rearview mirror
- 10 Glove compartment (page 45)
- 11 Remote control transmitter (page 26)
- 12 Beverage holder (page 46)
- 13 Shift lever (page 32)
- 14 Throttle lever (page 29)

### **Engine compartment**



- 2 Air filter case
- 3 Water separator (page 31)
- 4 Fuel tank
- 5 Battery (page 59)
- 6 Flushing hose connector
- 7 Watertight storage compartment
- 8 Spark plug/Spark plug cap/Ignition coil
- 9 Electrical box
- 10 Engine oil filler cap (page 51)


EJU31024

### Watercraft control functions

EJU41390

#### Remote control transmitter

The Yamaha Security System and Low RPM Mode settings can be selected by operating the remote control transmitter. (See page 27 for Yamaha Security System setting procedures and page 34 for Low RPM Mode activation procedures.)




#### 1 Remote control transmitter

Since the watercraft is programmed to recognize the internal code from this transmitter only, the settings can only be selected with this transmitter.

If you accidentally lose your remote control transmitter or if it is not operating properly, contact a Yamaha dealer.

When operating the watercraft, always keep the transmitter with you, such as by storing it in the transmitter holder in the beverage holder, so that it is not lost.



1 Transmitter holder

ECJ00752

#### NOTICE

- The remote control transmitter is not completely waterproof. Do not submerge the transmitter or operate it underwater. If the transmitter is submerged, dry it with a soft, dry cloth, and then check that it is operating properly. If the transmitter is not operating properly, contact a Yamaha dealer.
- Keep the remote control transmitter away from high temperatures and do not place it in direct sunlight.
- Do not drop the remote control transmitter, subject it to strong shocks, or place any heavy items on it.
- Use a soft, dry cloth to clean the remote control transmitter. Do not use detergent, alcohol, or other chemicals.
- Do not attempt to disassemble the remote control transmitter yourself. Otherwise, the transmitter may not operate properly. If the transmitter needs a new battery, contact a Yamaha dealer. Refer to local hazardous waste regulations when disposing of transmitter batteries.

EJU31384

### Yamaha Security System

The Yamaha Security System functions to help prevent unauthorized use or theft of the watercraft. The lock and unlock modes of the security system can be selected by operating the remote control transmitter that is included with this watercraft. The engine cannot be started if the lock mode of the security system is selected. The engine can only be started if the unlock mode is selected. (See page 26 for information on the remote control transmitter.)

#### TIP:

The Yamaha Security System settings can only be selected while the engine is stopped.

EJU37412

### Yamaha Security System settings

The Yamaha Security System settings will be confirmed by the number of beeps when the remote control transmitter is operated, and by the "UNLOCK" indicator light of the dual analog meter unit. (See page 36 for information on the dual analog meter unit.)


Number of beeps	Yamaha Security System mode	"UN- LOCK" in- dicator light
	Lock	Goes off
	Unlock (normal operation mode)	Comes on
	Unlock (Low RPM Mode)	Comes on


#### TIP:

- The beeper sounds two times for the normal operation mode or three times for the Low RPM Mode. (See page 34 for Low RPM Mode activation procedures.)
- If the remote control transmitter is operated while the dual analog meter unit is in the standby state, the unit will perform the initial operation, and then the setting is selected.

#### To select the lock mode:

Push the lock button on the remote control transmitter briefly. The beeper sounds once and the "UNLOCK" indicator light blinks once, then goes off. This indicates the lock mode is selected.






- 1 Lock button
- 2 "UNLOCK" indicator light

### To select the unlock mode:

Push the "L-Mode" (unlock) button on the remote control transmitter briefly. The beeper sounds two or three times and the "UNLOCK" indicator light blinks two or three times, then comes on. This indicates the unlock mode is selected.




- 1 "L-Mode" (unlock) button
- 2 "UNLOCK" indicator light

EJU31152

### Engine stop switch "\( \bigcirc\)"

The engine stop switch (red button) stops the engine when the switch is pushed.




1 Engine stop switch

EJU31163

### Engine shut-off switch "A"

The engine shut-off switch automatically stops the engine when the clip, on the end of the engine shut-off cord (lanyard), is removed from the switch, such as if the operator falls off the watercraft.


Insert the clip under the engine shut-off switch before starting the engine.



- 1 Engine shut-off switch
- 2 Clip
- 3 Engine shut-off cord (lanyard)

When the engine is not running, remove the clip from the engine shut-off switch to prevent

accidental starting or unauthorized operation by children or others.



Start switch "()"

ECJ01310


### **NOTICE**

Do not run the engine over 4000 r/min on land. Also, do not run the engine for more than 15 seconds without supplying water, otherwise the engine could overheat.

The start switch (green button) starts the engine when the switch is pushed.

Release the start switch as soon as the engine starts to run. If the engine does not start in 5 seconds, release the start switch, wait 15 seconds, and then try again. *NOTICE:* Never push the start switch while the engine is running. Do not operate the start switch for more than 5 seconds, otherwise the battery will be discharged and the engine

### will not start. Also, the starter motor could be damaged. [ECJ01040]



1 Start switch


The engine will not start under any of the following conditions:

- Lock mode of the Yamaha Security System has been selected. (See page 27 for Yamaha Security System setting procedures.)
- Clip is removed from the engine shut-off switch.
- Throttle lever is squeezed.

EJU31211

### Throttle lever

The throttle lever increases the engine speed when the lever is squeezed.




1 Throttle lever

The throttle lever returns automatically to its fully closed (idle) position when released.

FJU31261

### Steering system

By turning the handlebars in the direction you wish to travel, the angle of the jet thrust nozzle is changed, and the direction of the watercraft is changed accordingly.



- 1 Handlebar
- 2 Jet thrust nozzle

Since the strength of the jet thrust determines the speed and degree of a turn, throttle must always be applied when attempting a turn, except at trolling speed.

This model is equipped with the Yamaha Engine Management System (YEMS) that includes an off-throttle steering (OTS) system. It will activate at planing speeds should you attempt to steer the watercraft after releasing the throttle lever. The OTS system assists in turning by continuing to supply some thrust while the watercraft is decelerating, but you can turn more sharply if you apply throttle while turning the handlebars. The OTS system does not function below planing speeds or when the engine is off. Once the engine slows down, the watercraft will no longer turn

in response to handlebar input until you apply throttle again or you reach trolling speed.

EJU37341


### Telescopic steering system

The position of the handlebars can be adjusted up or down by operating the lock lever.

The handlebars can be adjusted to three positions.


#### To adjust the handlebar position:

(1) Pull the lock lever up to disengage the handlebar lock, and then move the handlebars up or down to the desired position. WARNING! Never pull the lock lever during operation, otherwise the handlebars may suddenly change position, which may lead to an accident.




1 Lock lever

[EWJ01270]




(2) Make sure that the lock lever returns to its original position and that the handlebars are securely locked in place.



EJU41800

### Cooling water pilot outlets

When the engine is running, some of the cooling water that is circulated in the engine is discharged from the cooling water pilot outlets.



1 Cooling water pilot outlet (port [left] side)

There are cooling water pilot outlets on the port (left) and starboard (right) sides of the watercraft. To check for proper operation of the cooling system, make sure that water is being discharged from the port (left) pilot outlet. If water is not being discharged from the outlet, stop the engine and check the jet intake for clogging. (See page 92 for information on the jet intake.)

#### TIP:

 It will take about 60 seconds for the water to reach the outlets after the engine is started.

# **Control function operation**


 Water discharge may not be constant when the engine is running at idling speed. If this occurs, apply a little throttle to make sure that water discharges properly.


EJU40322

### Water separator

The water separator prevents water from entering the fuel tank by collecting any water that has entered the fuel tank breather hose if the watercraft was capsized.

If water has collected in the water separator, drain it by loosening the drain screw.





1 Drain screw

### To drain water from the water separator:

- Place a drain pan or dry cloth under the water separator.
- (2) Gradually loosen the drain screw to drain the water. Catch the draining water in the drain pan or soak it up with the dry cloth so that it does not spill into the engine compartment. If any water spills into the

- watercraft, be sure to wipe it up with a dry cloth.
- (3) Securely tighten the drain screw until it stops.

EJU40011

## Watercraft operation functions

EJU37182

#### Reverse system

EWJ01230

# **WARNING**


- Do not use the reverse function to slow down or stop the watercraft as it could cause you to lose control, be ejected, or impact the handlebars.
- Make sure that there are no obstacles or people behind you before shifting into reverse.
- Do not touch the reverse gate while the shift lever is being operated, otherwise you could be pinched.

When the shift lever is moved to the reverse position, the reverse gate lowers and deflects the water jet being discharged from the jet thrust nozzle. This allows the watercraft to move in reverse.


### To shift into reverse:

- Release the throttle lever and let the engine speed return to idle.
- (2) Pull the shift lever rearward until it stops in the reverse position. The reverse gate

will lower and the watercraft will start moving in reverse at trolling speed.



- 1 Shift lever
- 2 Reverse position
- 3 Forward position



- 1 Reverse gate
- 2 Forward position
- 3 Reverse position

#### TIP:

This model is equipped with a function which limits the engine speed in reverse.


#### To shift into forward:

- (1) Release the throttle lever and let the engine speed return to idle.
- (2) Push the shift lever forward until it stops in the forward position. The reverse gate will rise and the watercraft will start moving forward at trolling speed.

EJU42640

## Quick Shift Trim System (Q.S.T.S.)

The Q.S.T.S. selector is integrated with the left handlebar grip and is operated to change the vertical angle of the jet thrust nozzle, which adjusts the trim angle of the watercraft. There are 5 positions: neutral, 2 bow-down positions (a) and (b), and 2 bow-up positions (c) and (d).



1 Q.S.T.S. selector

### Bow-down positions (a) and (b)

The bow will go down, causing the trim angle to decrease.

Vertical movement of the bow will be reduced and the watercraft will get up on plane more quickly when accelerating.

## Bow-up positions (c) and (d)

The bow will go up, causing the trim angle to increase.

There is less water resistance, therefore, straight-ahead acceleration is enhanced.

### TIP:

The watercraft performance characteristics according to the trim angle change depending on the operating conditions.









#### To change the trim angle:

- (1) Reduce engine speed to less than 3000 r/min.
- (2) Squeeze the Q.S.T.S. selector lock lever, and then turn the Q.S.T.S. selector to the desired position. NOTICE: Do not turn the Q.S.T.S. selector while operating the watercraft at an engine speed of

# 3000 r/min or more, otherwise damage could occur to the Q.S.T.S. IECJ000131





- 1 Q.S.T.S. selector
- 2 Q.S.T.S. selector lock lever
- (3) Release the lock lever, and then make sure that the Q.S.T.S. selector is securely locked in place.

#### EJU40000


## Watercraft operation modes

EJU37423

### **Low RPM Mode**

The Low RPM Mode is a function that limits the maximum engine speed to approximately 70% of the maximum engine speed in the normal mode.

The Low RPM Mode can only be activated and deactivated by operating the remote control transmitter that is included with this watercraft. (See page 26 for information on the remote control transmitter.)



Remote control transmitter

#### TIP:

The Low RPM Mode can only be activated when the engine is stopped in the unlock mode of the Yamaha Security System.

# Activating and deactivating the Low RPM Mode

Activation of the Low RPM Mode will be confirmed by the number of beeps when the remote control transmitter is operated, and by the "L-MODE" indicator light of the dual analog meter unit. (See page 36 for information on the dual analog meter unit.)

Number of beeps	Low RPM Mode operation	"L- MODE" indicator light
	Activated	Comes on
	Deactivated	Goes off

TIP:


If the remote control transmitter is operated while the dual analog meter unit is in the standby state, the unit will perform the initial operation, and then the setting is selected.

#### To activate the Low RPM Mode:

Push the "L-Mode" (unlock) button on the remote control transmitter for more than 4 seconds. Once the beeper sounds three times and the "UNLOCK" indicator light blinks three times, then comes on, the "L-MODE" indicator light comes on and the Low RPM Mode is activated

#### TIP:

If the Low RPM Mode is activated immediately after the information display turns off, the "L-MODE" indicator light will not come on. The "L-MODE" indicator light will come on when the engine is started.



- 1 "L-Mode" (unlock) button
- 2 "L-MODE" indicator light

#### To deactivate the Low RPM Mode:


Push the "L-Mode" (unlock) button on the remote control transmitter for more than 4 sec-

onds. Once the beeper sounds two times and the "UNLOCK" indicator light blinks two times, then comes on, the "L-MODE" indicator light goes off and the Low RPM Mode is deactivated. When the Low RPM Mode is deactivated, the watercraft returns to the normal operation mode.

FJU37432

## **Dual analog meter unit**

The dual analog meter unit displays various watercraft information.



- 1 Speedometer
- 2 Information display
- 3 Tachometer
- 4 "Hour Volt" button
- 5 "UNLOCK" indicator light
- 6 "L-MODE" indicator light
- 7 "WARNING" indicator light

### Dual analog meter unit initial operation

When the dual analog meter unit is activated, the speedometer and tachometer make one sweep, all of the display segments and indicator lights come on. After 2 seconds, the "WARNING" indicator light and the warning indicators in the information display go off, and then the unit starts to operate normally.

#### TIP:

The "UNLOCK" indicator light will go off when the engine is started.


### Dual analog meter unit standby state

If the dual analog meter unit does not receive any operation input within 25 seconds after the engine stops, the unit will turn off and enter a standby state. When the engine is started again, the displays return to their state before the unit turned off, and then the unit starts to operate normally. EJU37441

### Speedometer

The speedometer shows the watercraft speed against water.


The small outer numbers on the meter show the watercraft speed in kilometers per hour "km/h" and the large inner numbers show the speed in miles per hour "MPH".



EJU37242

#### **Tachometer**

The tachometer shows the engine speed. The inner numbers on the meter show the engine speed × 1000 RPM (r/min).



F II 135024

### Information display

The information display shows watercraft operating conditions.



- 1 Fuel level meter
- 2 Fuel indicator
- 3 Engine overheat warning indicator
- 4 Check engine warning indicator
- 5 Oil pressure warning indicator
- 6 Hour meter/voltmeter


F.II 137264

#### Hour meter/voltmeter

The hour meter/voltmeter has both an hour meter function and a voltmeter function. By switching the meter, it can be used as either an hour meter or a voltmeter.

#### TIP:

The hour meter is selected at the Yamaha factory.



Hour meter/voltmeter

#### Hour meter


The hour meter shows the total number of hours that the engine has been running since the watercraft was new.

#### TIP:

The elapsed time will be kept even if the battery terminals have been disconnected.

To switch to the hour meter from the voltmeter:

Push the "Hour Volt" button for at least 1 second. The display switches to the hour meter from the voltmeter.



- 1 "Hour Volt" button
- 2 Hour meter

#### Voltmeter


The voltmeter shows the battery voltage.

When the battery voltage is normal, the voltmeter displays approximately 12 volts.

If the battery voltage has dropped significantly, "LO" is displayed on the voltmeter. If the battery voltage has risen significantly, "HI" is displayed. If "LO" or "HI" is displayed, immediately return to shore and have a Yamaha dealer service the watercraft.

To switch to the voltmeter from the hour meter:

Push the "Hour Volt" button for at least 1 second. The display switches to the voltmeter from the hour meter.



- 1 "Hour Volt" button
- 2 Voltmeter


EJU37271

#### Fuel level meter

The fuel level meter shows the amount of fuel remaining in the fuel tank. The amount of remaining fuel is shown using four display segments, which disappear one at a time as the fuel level decreases.

#### TIP:

The accuracy of the fuel level meter varies depending on the operating conditions. Use this function as a reference only.




1 Fuel level meter

EJU37283

### Fuel level warning

If the fuel remaining in the fuel tank drops to about 18 L (4.8 US gal, 4.0 Imp. gal), the lowest fuel level segment, the fuel indicator, and the "WARNING" indicator light blink, and the buzzer sounds intermittently.



If the fuel level warning is activated, refill the fuel tank as soon as possible. (See page 49 for information on filling the fuel tank.)

After the fuel tank is refilled, the warning signals will be cleared when the engine is restarted.

### TIP:


Push the "Hour Volt" button to stop the buzzer.

EJU37293

#### Oil pressure warning

If the oil pressure drops significantly, the oil pressure warning indicator and the "WARN-ING" indicator light blink, and the buzzer

sounds intermittently. At the same time, the maximum engine speed is limited.



If the oil pressure warning is activated, immediately reduce the engine speed, return to shore, and then check the engine oil level. (See page 51 for information on checking the engine oil level.) If the oil level is sufficient, have a Yamaha dealer check the watercraft.


#### TIP:

Push the "Hour Volt" button to stop the buzzer.

EJU37303

#### **Engine overheat warning**

If the engine temperature rises significantly, the engine overheat warning indicator and the "WARNING" indicator light blink, and the buzzer sounds intermittently. Then, the engine overheat warning indicator and the "WARNING" indicator light stop blinking and remain on, and the buzzer sounds continuously. At the same time, the maximum engine speed is limited.



If the engine overheat warning is activated, immediately reduce the engine speed, return to shore, and then make sure that water is being discharged from the port (left) cooling water pilot outlet while the engine is running. If there is no discharge of water, stop the engine, and then check the jet intake for clogging. (See page 92 for information on the jet intake.) *NOTICE:* If you cannot locate and correct the cause of the overheating, consult a Yamaha dealer. Continuing to operate at higher speeds could result in severe engine damage. [ECJ000041]




#### TIP:

Push the "Hour Volt" button to stop the buzzer.

EJU37312

## Check engine warning

If a sensor malfunction or a short circuit is detected, the check engine warning indicator and the "WARNING" indicator light blink, and the buzzer sounds intermittently.



If the check engine warning is activated, immediately reduce the engine speed, return to shore, and have a Yamaha dealer check the engine.

## TIP:

Push the "Hour Volt" button to stop the buzzer.

FJU40333

# **Equipment**

EJU41410


#### Seats

The front and rear seats are removable.

Remove the seats to access the engine compartment and watertight storage compartment.


#### To remove the rear seat:

(1) Pull the rear seat latch up, and then lift up the rear of the seat.




1 Seat latch

(2) Pull the seat rearward and remove it.




### To install the rear seat:

(1) Insert the projections on the front of the seat into the stays on the deck.




(2) Push the rear of the seat down to securely lock it in place.




### To remove the front seat:

- (1) Remove the rear seat.
- (2) Pull the front seat latch up, and then lift up the rear of the seat.




(3) Pull the seat rearward and remove it.




### To install the front seat:

 Insert the projections on the front of the seat into the stays on the deck.



(2) Push the rear of the seat down to securely lock it in place.




(3) Securely install the rear seat in its original position.

EJU37371

## **Handgrips**


The handgrips are used when the spotter is facing rearward. WARNING! Do not use the handgrip to lift the watercraft. The handgrip is not designed to support the watercraft's weight. If the handgrip breaks, the watercraft could fall, which could result in severe injury. [EWJ00021]



EJU37381

## Reboarding grip

The reboarding grip is used when boarding the watercraft from the water.



1 Reboarding grip


EJU34864

### Reboarding step


The reboarding step is used to assist in reboarding the watercraft from the water.

When boarding the watercraft, push the reboarding step down until it stops. The step returns automatically to its original position when released. **WARNING!** Do not use the

reboarding step to lift the watercraft. The reboarding step is not designed to support the watercraft's weight. If the reboarding step breaks, the watercraft could fall, which could result in severe injury. [EMJ01211]



1 Reboarding step



NOTICE


Use the reboarding step only to board the watercraft in the water. Do not use the reboarding step for any other purpose. The watercraft can be damaged.

EJU34872

## Bow eye

The bow eye is used to attach a rope to the watercraft when transporting, mooring, or


towing it in an emergency. (See page 96 for information on towing the watercraft.)



EJU34881

### Stern eyes

The stern eyes are used to attach a rope to the watercraft when transporting or mooring it.




· Otom cy

#### EJU40420 Cleat

The cleat is used to attach a ski rope to the watercraft when pulling a water-skier.

WARNING! Do not use the cleat to lift the watercraft. The cleat is not designed to support the watercraft's weight. If the cleat

breaks, the watercraft could fall, which could result in severe injury. [EWJ01510]



EJU35146

### Storage compartments

This watercraft is equipped with the following storage compartments.

Only the securely closed watertight storage compartment is waterproof. If you carry objects that must be kept dry, put them in a waterproof bag.

Make sure that the storage compartments are closed securely before operating the water-craft.


F.II.I37331


### Bow storage compartment

The bow storage compartment is located under the hood.

To open the bow storage compartment:

Push the hood latch, and then lift up the rear of the hood.





1 Bow storage compartment

Bow storage compartment:

Capacity:

68.4 L (18.1 US gal, 15.0 Imp.gal)

Load limit:

5.0 kg (11 lb)


### To close the bow storage compartment:

Push the rear of the hood down to securely lock it in place.



To drain water from the bow storage compartment:

 Remove the drain plug on the bottom of the storage compartment to drain the water into the engine compartment.



Securely install the drain plug in its original position.


#### EJU31756

#### Glove compartment


The glove compartment is located in front of the seat.

#### To open the glove compartment:

Slide the glove compartment latch toward you, and then lift up the lid.



1 Glove compartment latch



1 Glove compartment

### Glove compartment:


Capacity:

3.5 L (0.9 US gal, 0.8 Imp.gal) Load limit:

1.0 kg (2 lb)


### To close the glove compartment:

Push the lid down to securely lock it in place.



To drain water from the glove compartment:

(1) Remove the beverage holder.



- 1 Beverage holder
- (2) Remove the drain plug on the bottom of the glove compartment to drain the water.



- 1 Drain plug
- (3) Securely install the drain plug in its original position.


(4) Securely install the beverage holder in its original position.

FJU41420

### Beverage holder

The beverage holder is located in the glove compartment. (See page 45 for information on the glove compartment.)

The beverage holder is removable.



1 Beverage holder

Do not place any items in the beverage holder while riding. Otherwise, the items may fall out of the beverage holder.

EJU37233

## Watertight storage compartment

The watertight storage compartment is located under the rear seat.


The compartment is watertight when the cap is closed securely.

The watertight storage compartment is removable.


To open the watertight storage compartment:

 Remove the rear seat. (See page 41 for seat removal and installation procedures.)

(2) Loosen the cap and remove it.



1 Watertight storage compartment cap



- Tratoragin otorago comparament

Watertight storage compartment: Capacity:

8.7 L (2.3 US gal, 1.9 Imp.gal) Load limit:

3.0 kg (7 lb)

## To close the watertight storage compartment:

- Securely install the cap by tightening it until it stops.
- (2) Securely install the rear seat in its original position.


F.II I41282

## Fire extinguisher holder and cover


The fire extinguisher holder and cover are located in the bow storage compartment.

To use the fire extinguisher holder and cover:

 Push the hood latch, and then lift up the rear of the hood.




(2) Unhook the band and remove the fire extinguisher cover.



- 1 Band
- 2 Fire extinguisher holder and cover
- (3) Place the fire extinguisher in the holder, and then place the cover over the fire extinguisher.
- (4) Securely fasten the cover and the fire extinguisher with the band.
- (5) Push the rear of the hood down to securely lock it in place. Make sure that the

hood is securely closed before using the watercraft.



EJU31822

## **Fuel requirements**

Fuel

# WARNING

- Gasoline and gasoline vapors are extremely flammable. To avoid fires and explosions and to reduce the risk of injury when refueling, follow these instructions.
- Gasoline is poisonous and can cause injury or death. Handle gasoline with care.
   Never siphon gasoline by mouth. If you should swallow some gasoline, inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immediately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

ECJ00321

## **NOTICE**

- Do not use leaded gasoline. Leaded gasoline can seriously damage the engine.
- Avoid getting water and contaminants in the fuel tank. Contaminated fuel can cause poor performance and engine damage. Use only fresh gasoline that has been stored in clean containers.

#### Recommended fuel:

Regular unleaded gasoline with a minimum octane rating of 86

(Pump octane number) = (R + M)/2 90 (Research octane number)

#### Gasohol


There are two types of gasohol: gasohol containing ethanol and that containing methanol. Gasohol containing ethanol can be used if ethanol content does not exceed 10% and the

fuel meets the minimum octane ratings. E-85 is a fuel blend containing 85% ethanol and therefore must not be used in this watercraft. All ethanol blends containing more than 10% ethanol can cause fuel system damage or engine performance problems.


Yamaha does not recommend gasohol containing methanol because it can cause fuel system damage and engine performance problems.

### To fill the fuel tank:

- (1) Before refueling, stop the engine. Do not stand or sit on the watercraft. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition.
- (2) Place the watercraft in a well-ventilated area and in a horizontal position.
- (3) Remove the seats, and then check the fuel level. (See page 41 for seat removal and installation procedures.)
- (4) Push the hood latch, and then lift up the rear of the hood.




(5) Loosen the fuel filler cap and remove it.




- 1 Fuel filler cap
- (6) Slowly add fuel to the fuel tank.


Fuel tank capacity: 70 L (18.5 US gal, 15.4 Imp.gal)



(7) Stop filling when the fuel level reaches approximately 50 mm (2 in) from the top of the fuel tank. Do not overfill the fuel tank. Because fuel expands when it heats up, heat from the engine or the sun can cause fuel to spill out of the fuel tank. Do not leave the watercraft with a full tank in direct sunlight.



- 1 Approximately 50 mm (2 in) from top of the fuel tank
- (8) Wipe up any spilled fuel immediately with a dry cloth.
- (9) Securely install the fuel filler cap by tightening it until it clicks.
- (10) Push the rear of the hood down to securely lock it in place. Make sure that the fuel filler cap and the hood are securely closed before using the watercraft.



(11) Securely install the seats in their original positions.

EJU40290

## **Engine oil requirements**

EJU41510

**Engine oil** 

ECJ00281

### **NOTICE**

Use only 4-stroke engine oil. Usage of 2stroke engine oil could result in severe engine damage.

Recommended engine oil type: SAE 10W-30, 10W-40, 20W-40, 20W-50

Recommended engine oil grade: API SE,SF,SG,SH,SJ,SL

## Checking the engine oil level

EWJ00340

# **WARNING**

Engine oil is extremely hot immediately after the engine is turned off. Coming in contact with or getting any engine oil on your clothes could result in burns.

ECJ01001


## NOTICE

Make sure that debris and water do not enter the oil filler hole. Debris and water in the engine oil can cause serious engine damage.


## To check the engine oil level:

- (1) Place the watercraft in a precisely level position on land with the engine stopped. If the engine was running, allow the engine oil to settle by waiting 5 minutes or more before checking the oil level.
- (2) Remove the seats. (See page 41 for seat removal and installation procedures.)

(3) Remove the dipstick and wipe it clean.




- 1 Dipstick
- (4) Insert the dipstick back into the dipstick tube completely. Remove the dipstick again and make sure that the engine oil level is between the minimum and maximum level marks.



- 1 Maximum level mark
- 2 Minimum level mark
- (5) If the engine oil level is significantly above the maximum level mark, consult a Yamaha dealer. If the engine oil level is below the minimum level mark, add engine oil.

(6) Loosen the engine oil filler cap and remove it.



- 1 Engine oil filler cap
- (7) Slowly add engine oil.

### TIP:

The difference between the minimum and maximum level marks on the dipstick is equal to approximately 1 L (1.06 US qt, 0.88 Imp. qt) of engine oil.

- (8) Wait approximately 5 minutes to allow the engine oil to settle, and then check the engine oil level again.
- (9) Repeat steps 3–8 until the engine oil is at the proper level.
- (10) Securely install the engine oil filler cap by tightening it until it stops.
- (11) Securely install the seats in their original positions.

EJU40021

# Draining the bilge water

ECJ01301

### **NOTICE**


Do not run the engine at full throttle when bilge water remains in the engine compartment. The bilge water can splash into the engine, which can result in severe damage.

EJU40033

# Draining the bilge water on land

To drain the bilge water on land:

 Loosen the stern drain plugs and remove them.



1 Stern drain plug



- (2) Raise the bow of the watercraft, such as by placing the watercraft on a slope, to drain the bilge water from the engine compartment.
- (3) After the bilge water has drained from the stern drain plug holes, wipe up any re-

maining moisture in the engine compartment with a dry cloth.

(4) Securely install the stern drain plugs by tightening them until they stop. NOTICE: Before installing the stern drain plugs, clean the drain plug threads to remove any foreign materials, such as dirt or sand. Otherwise, the stern drain plugs could be damaged, allowing water to enter the engine compartment. Make sure that the stern drain plugs are tightened securely before launching the watercraft. Otherwise, water may flood the engine compartment and cause the watercraft to submerge.

[ECJ00361]

EJU40043

### Draining the bilge water on water

A small quantity of bilge water will remain in the engine compartment even after the bilge water is drained on water. To completely drain the bilge water, remove the watercraft from the water and drain the bilge water on land.


### Jet vacuum bilge draining system

While the watercraft is operating, bilge water in the engine compartment is drawn in by the vacuum that is generated in the jet pump and discharged from the watercraft through the jet thrust nozzle.

### To drain the bilge water on water:

Operate the watercraft as straight as possible and above planing speed for at least 2 minutes. *NOTICE:* Do not run the engine at full throttle for at least 1 minute after the engine has been restarted. Bilge water in the engine compartment can splash into the


engine, which can result in severe damage. [ECJ00553]



## Electric bilge draining system

Bilge water in the engine compartment is drawn in by the operation of the electric bilge pump and discharged from the watercraft.

To check for proper operation of the electric bilge draining system, make sure that bilge water is being discharged from the electric bilge pilot outlet.



1 Electric bilge pilot outlet

## To drain the bilge water:

Start the engine to operate the electric bilge pump.


#### TIP:

The electric bilge pump continues to operate for a short time after the engine stops.

EJU33464

# Transporting on a trailer

When transporting the watercraft on a trailer, secure the tie downs to the trailer through the bow eye and stern eyes. *NOTICE:* Do not attach ropes or tie downs to any part of the watercraft other than the bow eye and stern eyes to secure the watercraft to the trailer. Otherwise, the watercraft may be damaged. Wrap the ropes or tie downs with towels or rags where they touch the body of the watercraft to avoid scratches or damage. Do not transport the watercraft with the shift lever in the reverse position. Otherwise, the reverse gate may hit an obstacle, which could cause damage. [ECJ000644]



FJU36665

## **Engine break-in**

ECJ00431

## NOTICE

Failure to perform the engine break-in could result in reduced engine life or even severe engine damage.

The engine break-in is essential to allow the various components of the engine to wear and polish themselves to the correct operating clearances. This ensures proper performance and promotes longer component life.

### To perform the engine break-in:

- Check the engine oil level. (See page 51 for information on checking the engine oil level.)
- (2) Launch the watercraft and start the engine. (See page 67 for information on starting the engine.)
- (3) For the first 5 minutes, operate with the engine speed at 2000 r/min.
- (4) For the next 30 minutes, operate with the engine speed below 5000 r/min.
- (5) For the next 1 hour, operate with the engine speed below 6000 r/min.

After the engine break-in is complete, the watercraft can be operated normally.

EJU31981

EWJ00411



Failure to inspect or maintain the watercraft properly increases the possibility of an accident or damage to the watercraft. Do not operate the watercraft if you find any problem. If a problem cannot be corrected by the procedures provided in this manual, have the watercraft inspected by a Yamaha dealer.

EJU41232

### **Pre-operation checklist**

Before using this watercraft, be sure to perform the checks in the following checklist.

ITEM	ROUTINE	PAGE
PRE-LAUNCH CHECKS		
Engine compartment	Ventilate the engine compartment. Check inside the engine compartment for damage.	58
Fuel system	Check the fuel system for leakage. Check the fuel level in the fuel tank.	58
Water separator	Check the water separator for water.	58
Engine unit	Check the exterior of the engine unit for damage.	59
Engine oil level	Check the engine oil level.	59
Bilge water	Check the engine compartment for bilge water.	59
Battery	Check the battery connections and electrolyte level.	59
Steering system	Check the steering system for proper operation.	60
Telescopic steering system	Check the telescopic steering system for proper operation and check that the handlebars are securely locked in place.	60
Q.S.T.S.	Check the Q.S.T.S. for proper operation and check that the Q.S.T.S. selector is securely locked in place.	61
Reverse system	Check the reverse system for proper operation.	61
Throttle lever	Check the throttle lever for proper operation. Check the throttle lever free play.	62
Remote control transmitter	Check the remote control transmitter for proper operation.	62
Engine shut-off cord (lan- yard)	Check the engine shut-off cord (lanyard) for damage.	63
Switches	Check the start switch, engine stop switch, and engine shut-off switch for proper operation.	63
Storage compartments	Check the storage compartments for damage and water.	63
Fire extinguisher holder, cover, and band	Check the fire extinguisher holder, cover, and band for damage.	64
Fire extinguisher	Check the condition of the fire extinguisher.	64
Safety equipment	Check that safety equipment meeting the applicable regulations is on board.	64

ITEM	ROUTINE	PAGE	
Hull and deck	Check the hull and deck for damage.	64	
Jet intake	Check the jet intake for damage and clogging.	64	
Stern drain plugs	Check the stern drain plugs for damage and foreign material and check that they are securely installed.	64	
Hood	Check that the hood is securely closed.	65	
Front and rear seats	Check that the seats are securely installed.	41	
POST-LAUNCH CHECKS			
Cooling water pilot outlet	Check that water is discharged from the port (left) cooling water pilot outlet while the engine is running.	65	
Dual analog meter unit	Check the dual analog meter unit for proper operation.	65	
Engine idling speed	Check the engine idling speed.	65	

## TIP:

To ensure safety and reliability, pre-operation checks should be made each time the watercraft is used.

F.II I32281

## **Pre-operation check points**

EJU41311

#### Pre-launch checks

Perform the pre-launch checks in the pre-operation checklist while the watercraft is on land.

### To perform the pre-launch checks:

- (1) Remove the seats and watertight storage compartment. (See page 41 for seat removal and installation procedures and page 46 for information on the watertight storage compartment.)
- (2) Perform the checks and make sure that there are no malfunctioning items or other problems.
- (3) After completing these checks, securely install the watertight storage compartment and seats in their original positions.

EJU3233

**Engine compartment check** 


EWJ0046



Failure to ventilate the engine compartment could result in a fire or explosion. Do not start the engine if there is a fuel leak.

Ventilate the engine compartment. Leave the engine compartment open for a few minutes to allow any fuel vapors to escape.

Make sure that there is no damage inside the engine compartment.



FJU34214

#### Fuel system checks

EWJ00381

## WARNING

Leaking fuel can result in fire or explosion.

- Check for fuel leakage regularly.
- If any fuel leakage is found, the fuel system must be repaired by a qualified mechanic. Improper repairs can make the watercraft unsafe to operate.

Make sure that there is no damage, leakage, or other problem in the fuel system.

#### Check:

- Fuel filler cap and seal for damage
- Fuel tank for damage and leakage
- Fuel hoses and joints for damage and leakage
- Fuel tank breather hose for damage and leakage

EJU36874

#### Fuel level check


Check the fuel level in the fuel tank.

Add fuel if necessary. (See page 49 for information on filling the fuel tank.)

#### EJU32423

#### Water separator check

Make sure that no water has collected in the water separator. If water has collected in the water separator, drain it. (See page 31 for information on draining the water separator.)



Water separator

EJU40181


### **Engine unit check**


Check the exterior of the engine unit for damage or other problem.

EJU36885

#### Engine oil level check

Make sure that the engine oil level is between the minimum and maximum level marks on the dipstick. (See page 51 for information on checking the engine oil level.)





- 1 Maximum level mark
- 2 Minimum level mark

F.II 132455

#### Bilge water check


Make sure that no bilge water has collected in the engine compartment. If bilge water has collected in the engine compartment, drain it. (See page 52 for information on draining the bilge water.)

EJU32484

#### **Battery checks**


Make sure that the battery terminals and breather hose are not damaged and that the

battery leads and breather hose are connected properly. WARNING! Fire or explosion could result if the breather hose is damaged, obstructed, or not connected properly. [EWJ00451]



- 1 Negative (-) battery terminal: Black lead
- 2 Positive (+) battery terminal: Red lead
- 3 Breather hose

Make sure that the electrolyte level is between the minimum and maximum level marks. WARNING! Never operate the watercraft if the battery does not have sufficient power to start the engine or if it shows any other signs of decreased power. Loss of battery power may leave you stranded. [EWJ01240]




- 1 Maximum level mark
- 2 Minimum level mark

Make sure that the battery is securely held in place.

EJU32613


#### Steering system checks


Turn the handlebars to the right and left several times to make sure that operation is smooth and unrestricted throughout the whole range, and that the free play is not excessive.



Turn the handlebars as far as possible to the right and left to make sure that the jet thrust nozzle moves as the handlebars are turned, and that there is no difference between the

right and left fully turned positions of the jet thrust nozzle.





Difference between fully turned positions of jet thrust nozzle (distances A and B):
Maximum 5 mm (0.20 in)


EJU41320

### Telescopic steering system checks

Operate the telescopic steering system several times to make sure that operation is smooth throughout the whole range. Also, make sure that the handlebars are securely


locked in place. (See page 30 for telescopic steering system operation procedures.)

curely locks in place. (See page 33 for Q.S.T.S. operation procedures.)



EJU32644

Quick Shift Trim System (Q.S.T.S.) checks Operate the Q.S.T.S. selector lock lever and the Q.S.T.S. selector several times to make sure that operation is smooth throughout the whole range. Also, make sure that the jet thrust nozzle moves as the Q.S.T.S. selector is operated and that the Q.S.T.S. selector se-



EJU32634


Reverse system checks



Do not touch the reverse gate while the shift lever is being operated, otherwise you could be pinched.

Operate the shift lever several times to make sure that operation is smooth throughout the whole range. Also, make sure that the reverse

gate moves up and down according to the operation of the shift lever and that the gate makes contact with the stoppers. (See page 32 for reverse system operation.)




1 Stopper


EJU41431

#### Throttle lever checks


Operate the throttle lever several times to make sure that operation is smooth throughout the whole range. Also, make sure that the throttle lever returns automatically to its fully closed (idle) position when released.



Face the handlebars straight ahead with the handlebars in the lowest position and the throttle lever in the fully closed (idle) position, and then make sure that there is the proper amount of throttle lever free play when the throttle lever is in the fully closed (idle) position. (See page 30 for telescopic steering system operation procedures.)



1 Lowest position with handlebars facing straight ahead



1 Throttle lever free play

Throttle lever free play: 2.0–5.0 mm (0.08–0.20 in)

#### F.II.I40112


#### Remote control transmitter check

Make sure that the remote control transmitter operates properly. (See page 27 for Yamaha Security System setting procedures and page 34 for Low RPM Mode activation procedures.)

EJU32663

### Engine shut-off cord (lanyard) check

Make sure that the engine shut-off cord (lanyard) is not damaged. If the cord is damaged, replace it. WARNING! Never try to repair the engine shut-off cord (lanyard) or tie it together. The engine shut-off cord (lanyard) may not pull free when the operator falls off, allowing the watercraft to continue to run and cause an accident. [EWJ01220]




EJU32675 Switch checks

ECJ01310

## NOTICE

Do not run the engine over 4000 r/min on land. Also, do not run the engine for more than 15 seconds without supplying water, otherwise the engine could overheat.

Check the start switch, the engine stop switch, and the engine shut-off switch for proper operation. (See pages 28 to 28 for information on operating each switch.)



- 1 Engine shut-off switch
- 2 Clip
- 3 Start switch
- 4 Engine stop switch
- 5 Engine shut-off cord (lanyard)

### To check the operation of the switches:

- If the lock mode is selected for the Yamaha Security System setting, select the unlock mode. (See page 27 for Yamaha Security System setting procedures.)
- (2) Push the start switch to make sure that the engine starts.
- (3) As soon as the engine starts running, push the engine stop switch to make sure that the engine stops immediately.
- (4) Restart the engine, and then pull the engine shut-off cord (lanyard) to remove the clip from the engine shut-off switch to make sure that the engine stops immediately.

FJU40101

## Storage compartment checks

Make sure that the storage compartments are not damaged and that water has not collected in the compartments. (See page 44 for information on the storage compartments.)

EJU41081

# Fire extinguisher holder, cover, and band checks

Make sure that the fire extinguisher holder, cover, and band are not damaged and that the cover is securely held in place using the band. (See page 47 for information on the fire extinguisher holder, cover, and band.)

FJU32543

#### Fire extinguisher check

Check that there is a full fire extinguisher on board.



To check the fire extinguisher, see the instructions supplied by the fire extinguisher manufacturer. Always keep the fire extinguisher secured in the holder with its cover in place. Always carry a fire extinguisher on board. A fire extinguisher is not standard equipment with this watercraft. If you do not have one, contact a Yamaha dealer or a fire extinguisher dealer to obtain one meeting the proper spec-

ifications.

#### Safety equipment check

Check that safety equipment meeting the applicable regulations is on board.

EJU32352

#### Hull and deck check

Check the hull and deck for damage or other problem.

F.II.132656

#### Jet intake checks

Make sure that the jet intake is not damaged or clogged with weeds or debris. If the jet in-

take is clogged, clean it. (See page 92 for information on the jet intake.)


FJU32475

### Stern drain plug checks

Loosen the stern drain plugs and remove them, and then make sure that the plugs are not damaged and that there is no foreign material on the threads. NOTICE: Before installing the stern drain plugs, clean the drain plug threads to remove any foreign materials, such as dirt or sand. Otherwise, the stern drain plugs could be damaged, allowing water to enter the engine compartment. Make sure that the stern drain plugs are tightened securely before launching the watercraft. Otherwise, water may flood the engine compartment and cause the watercraft to submerge. [ECJ00361] Securely install the stern drain plugs by tightening them until they stop.




1 Stern drain plug



FJU41440

#### Hood check

Push down on the rear of the hood and make sure that it is securely closed.



EJU40144

#### Post-launch checks

Perform the post-launch checks in the pre-operation checklist while the watercraft is in the water and the engine is running.


#### To perform the post-launch checks:

- (1) Launch the watercraft. (See page 67 for information on launching the watercraft.)
- (2) Perform the checks and make sure that there are no malfunctioning items or other problems.

EJU41810

### Cooling water pilot outlet check


Make sure that water is discharged from the port (left) cooling water pilot outlet while the engine is running. (See page 30 for information on the cooling water pilot outlets.)



FJU37451

#### Dual analog meter unit check

Make sure that the dual analog meter unit operates properly. (See page 36 for information on proper operation of the dual analog meter unit.)



EJU41330

#### Engine idling speed check

Start the engine and warm it up. Use the tachometer in the dual analog meter unit to make sure that the engine idling speed is not significantly above or below the specified range.

Engine idling speed: 1250 ±100 r/min

# **Operation**

F.II 132902

## Operating your watercraft

EWJ00510



Before operating your watercraft, become familiar with all of the controls. Consult a Yamaha dealer about any control or function that you do not fully understand. Failure to understand how the controls work could cause an accident or prevent you from avoiding an accident.

EJU32963

### Getting to know your watercraft

Operating your watercraft requires skills acquired through practice over a period of time. Take the time to learn the basic techniques well before attempting more difficult maneuvers.

Operating your new watercraft can be a very enjoyable activity, providing you with hours of pleasure. However, it is essential to familiarize yourself with the operation of the watercraft to achieve the skill level necessary to enjoy riding safely.

Before operating this watercraft, read this owner's/operator's manual, the Riding Practice Guide, the Riding Instruction card, and all labels on the watercraft. Pay particular attention to the safety information beginning on page 11. These materials should give you an understanding of the watercraft and its operation.

Remember: This watercraft is designed to carry the operator and up to 2 passengers. Never exceed the maximum load limit or allow more than 3 persons (or 2 persons if a waterskier is being pulled) to ride the watercraft at any time.

Maximum load:

240 kg (530 lb)

Load is the total weight of cargo, operator, and passengers.


EJU33005

#### Learning to operate your watercraft

Before operating the watercraft, always perform the pre-operation checks listed on page 56. The short time spent checking the watercraft will reward you with added safety and reliability.

Check local laws before operating your watercraft.

Operate defensively at safe speeds and keep a safe distance away from people, objects, and other watercraft. Select a wide area to learn in, where there is good visibility and light boat traffic.



Use the buddy system—operate with someone nearby. Scan constantly for people, objects, and other watercraft. Be alert for conditions that limit your visibility or block your vision of others.

You should grip the handlebars firmly and keep both feet on the floor of the footwell. Do not attempt to ride with passengers until your operating skills are fully developed.

EJU40210

#### Riding position

#### Operator riding position

The operator should grip the handlebars firmly with both hands and sit astride the seat with both feet on the floor of the footwell.



#### Passenger riding position

The passenger(s) should hold on firmly, either to the person in front of them or to the hand-grip provided, and sit astride the seat with their feet on the floor of the footwell. Never allow a passenger to ride in front of the operator. (See page 18 for information on the riding position when pulling a water-skier.)



EJU32802

#### Launching the watercraft

When launching the watercraft, make sure that there are no obstacles around you.

If the watercraft is launched from a trailer, someone should make sure that waves do not push the watercraft into the trailer.

E II 136345

#### Starting the engine on water


EWJ01530

## **♠** WARNING

Do not apply throttle when anyone is at the rear of the watercraft. Turn the engine off or keep it at idle. Water and debris exiting the jet thrust nozzle can cause severe injury.

#### To start the engine:


- (1) If the lock mode is selected for the Yamaha Security System setting, select the unlock mode. (See page 27 for Yamaha Security System setting procedures.)
- (2) Move the watercraft to an area that is free from weeds and debris, and has a water depth of at least 60 cm (2 ft) from the bottom of the watercraft. *NOTICE:* Never run the engine in water that is less than 60 cm (2 ft) deep from the bottom of the watercraft, otherwise pebbles or sand could be sucked into the jet intake, causing impeller damage and engine overheating. [ECJO0472]




(3) Attach the engine shut-off cord (lanyard) to your left wrist, and then attach the clip to the engine shut-off switch. (See page 28 for information on operating the engine shut-off switch.) WARNING! Check that the engine shut-off cord (lanyard)

## **Operation**

is attached correctly. If the engine shut-off cord (lanyard) is not attached correctly, it may not pull free when the operator falls off, allowing the watercraft to continue to run and cause an accident. IEWJ005811



- 1 Clip
- 2 Engine shut-off switch
- 3 Engine shut-off cord (lanyard)
- (4) With the throttle lever released, push the start switch (green button) to start the engine. (See page 28 for information on operating the start switch.)




EJU32862

#### Stopping the engine

Release the throttle lever, and then push the engine stop switch (red button) to stop the engine. WARNING! You need throttle to steer. Shutting the engine off can cause you to hit an obstacle you are attempting to


avoid. A collision could result in severe injury or death. [EWJ00601]



FJU32872

#### Leaving the watercraft


If leaving the watercraft, remove the clip from the engine shut-off switch to prevent accidental starting or unauthorized operation by children or others.



EJU40221

## Operating the watercraft

When the shift lever is in the forward position and the engine is running, the watercraft will move forward. The watercraft will move forward at trolling speed even if the throttle lever is in the fully closed (idle) position. (See page 32 for information on operating the shift lever.)



- 1 Shift lever
- 2 Forward position



EJU33254

#### Turning the watercraft

EWJ0077

## **WARNING**


- Do not release the throttle lever when trying to steer away from objects—you need throttle to steer. A collision could result in severe injury or death.
- When operating at higher speeds, make gradual turns or slow down before turning. Sharp high-speed turns may cause the watercraft to slide sideways or spin, throwing the operator and passenger(s) overboard, which could cause an injury.

Steering control depends on the combination of handlebar position and the amount of throttle.


Water sucked in through the intake grate is pressurized by the impeller in the jet pump. As the pressurized water is expelled from the pump through the jet thrust nozzle, it creates thrust to move and steer the watercraft. The higher the engine speed, the more thrust produced.

The amount of jet thrust, in addition to the position of the handlebars, determines how sharply you turn.

A. More throttle produces higher thrust, so the watercraft will turn more sharply.



B. Less throttle produces lower thrust, so the watercraft will turn more gradually.




C. Releasing the throttle lever completely produces only minimum thrust. If you are traveling at speeds above trolling, you will have rapidly decreasing ability to steer without throttle. You may still have some turning ability immediately after releasing the throttle lever, but once the engine


## **Operation**

slows down, the watercraft will no longer respond to handlebar input until you apply throttle again or you reach trolling speed.

At trolling speed, the watercraft can be turned gradually by handlebar position alone using just the amount of thrust available at idle.



D. If the engine is stopped while riding, there is no thrust. The watercraft will go straight even though the handlebars are turned.



#### You need throttle to steer.

This model is equipped with the Yamaha Engine Management System (YEMS) that includes an off-throttle steering (OTS) system. It will activate at planing speeds should you attempt to steer the watercraft after releasing the throttle lever (see condition C above).


The OTS system assists in turning by continuing to supply some thrust while the watercraft is decelerating, but you can turn more sharply

if you apply throttle while turning the handlebars. The OTS system does not function below planing speeds or when the engine is off. Once the engine slows down, the watercraft will no longer turn in response to handlebar input until you apply throttle again or you reach trolling speed.

EJU37513

#### Stopping the watercraft

The watercraft is not equipped with a separate braking system. It is stopped by water resistance when the throttle lever is released. From full speed, the watercraft comes to a complete stop in approximately 130 m (430 ft) after the throttle lever is released or the engine is stopped, although this distance will vary depending on many factors, including gross weight, water surface conditions, and wind direction. The watercraft slows down as soon as the throttle lever is released, but will coast for a distance before fully stopping. If you are not sure you can stop in time before hitting an obstacle, apply throttle and turn in another direction.



EWJ00744

### **WARNING**

- Allow adequate stopping distance.
- Take early action to avoid collisions. Remember, watercraft and other boats do not have brakes.
- Operate defensively at safe speeds and keep a safe distance away from people,


objects, and other watercraft to give you time to stop.

- Do not shut the engine off when slowing down in case you need engine power to steer away from a boat or other obstacle that comes into your path.
- Do not use the reverse function to slow down or stop the watercraft as it could cause you to lose control, be ejected, or impact the handlebars.

EJU40371

#### Operating the watercraft in reverse

Pull the shift lever rearward to the reverse position. The watercraft will move in reverse. (See page 32 for information on the reverse system.)



- 1 Shift lever
- 2 Reverse position



Make sure that there are no obstacles or people behind you before shifting into reverse.

#### TIP:

This model is equipped with a function which limits the engine speed in reverse.

EJU36086

## **Boarding the watercraft**


FW.I01111

## **WARNING**

Be sure the operator and any passengers have practiced boarding from the water while still close to shore before riding. A person who has made many unsuccessful attempts to get back on the watercraft may become fatigued and suffer from exposure, increasing the risk of injury and drowning.

Board the watercraft in water free from weeds and debris and at least 60 cm (2 ft) deep from the bottom of the watercraft. *NOTICE:* Never run the engine in water that is less than 60 cm (2 ft) deep from the bottom of the watercraft, otherwise pebbles or sand could be sucked into the jet intake, causing impeller damage and engine overheating.

[ECJ00472]



#### TIP:

This watercraft is equipped with a reboarding step, which can be lowered and used to assist in reboarding. (See page 42 for information on operating the reboarding step.)

## **Operation**

F.II.I37463

#### **Boarding alone**

- (1) From the rear of the watercraft, place both hands on the boarding platform, pull yourself up, and then grasp the reboarding grip with one hand.
- (3) Attach the engine shut-off cord (lanyard) to your left wrist, and then attach the clip to the engine shut-off switch.
- (4) Grip the handlebars with both hands and place both feet on the floor of the footwell.





(5) Look in all directions, start the engine, and then start off slowly.

EJU33169

Boarding with passenger(s)


**₩ARNING** 

EWJ00660



Severe internal injuries can occur if water is forced into body cavities as a result of being near the jet thrust nozzle. Do not apply throttle until the passengers are seated with their feet on the floor of the footwell and are securely holding on to the person in front of them or to the handgrip provided.

The heavier the total weight of the operator and passenger(s), the more difficult it will be to balance the watercraft. Do not operate the watercraft when the total weight exceeds 240 kg (530 lb) including any cargo.



(2) Pull yourself up to a kneeling position on the boarding platform, and then move to the seat and sit astride.



#### To board at a standstill:


(1) Board as noted in the previous section "Boarding alone".

their feet on the floor of the footwell, and securely hold on to the operator.





- (2) Attach the engine shut-off cord (lanyard) to your left wrist, and then attach the clip to the engine shut-off switch.
- (3) Grip the handlebars with both hands and place both feet on the floor of the footwell.
- (4) Have the first passenger move to the rear of the watercraft.







(5) Have the first passenger board using the same procedure as the operator, place

(7) Make sure that the passenger(s) have their feet on the floor of the footwell and are securely holding on to the person in front of them or to the handgrip provided.



## **Operation**

(8) Look in all directions, start the engine, and then start off slowly.

To board when it is difficult to balance at a standstill:

(1) Have the passenger(s) steady the watercraft, and then board as noted in the previous section "Boarding alone". senger crawl onto the seat while maintaining their balance.



- (2) Grip the handlebars with both hands, place both feet on the floor of the footwell, and balance there.
- (3) Have the first passenger board using the same procedure as the operator, place their feet on the floor of the footwell, securely hold on to the operator, and balance there.
- (4) Attach the engine shut-off cord (lanyard) to your left wrist, and then attach the clip to the engine shut-off switch.
- (5) Look in all directions, and then start the engine and operate at trolling speed.
- (6) Have the second passenger pull themselves up onto the boarding platform into a kneeling position and balance there. Look in all directions, and then gradually accelerate. Then, have the second pas-

- (7) Have the second passenger sit astride the seat, place their feet on the floor of the footwell, securely hold on to the person in front of them or to the handgrip provided, and balance there.
- (8) Make sure that the passenger(s) have their feet on the floor of the footwell and are securely holding on to the person in front of them or to the handgrip provided, and then gradually increase the speed to balance the watercraft.



Starting off

=W 100711



To avoid collisions:


 Scan constantly for people, objects, and other watercraft. Be alert for conditions that limit your visibility or block your vision of others.

- Operate defensively at safe speeds and keep a safe distance away from people, objects, and other watercraft.
- Do not follow directly behind watercraft or other boats. Do not go near others to spray or splash them with water. Avoid sharp turns or other maneuvers that make it hard for others to avoid you or understand where you are going. Avoid areas with submerged objects or shallow water.
- Take early action to avoid collisions. Remember, watercraft and other boats do not have brakes. Do not release the throttle lever when trying to steer away from objects—you need throttle to steer.

ECJ01340

### NOTICE

Never run the engine in water that is less than 60 cm (2 ft) deep from the bottom of the watercraft, otherwise pebbles or sand could be sucked into the jet intake, causing impeller damage and engine overheating.



EJU40232

### Starting off from a trailer

 Launch the watercraft and move the shift lever to the reverse position. (See page 32 for information on the reverse system.)

- (2) Attach the engine shut-off cord (lanyard) to your left wrist, and then attach the clip to the engine shut-off switch.
- (3) Look in all directions, start the engine, and then start off slowly.

EJU33113

#### Boarding and starting off from a dock

- (1) Board the watercraft from the side.
- (2) Attach the engine shut-off cord (lanyard) to your left wrist, and then attach the clip to the engine shut-off switch.
- (3) Push the watercraft away from the dock, grip the handlebars with both hands, and place both feet on the floor of the footwell.



(4) Look in all directions, start the engine, and then start off slowly.

F II 133235

#### Capsized watercraft

EW.J00671

## **WARNING**

Improper uprighting can cause injury.

- Be sure to shut the engine off by pulling on the engine shut-off cord (lanyard) to remove the clip from the engine shut-off switch.
- Do not put your hands in the intake grate.

If the watercraft capsizes, turn it over immediately.

#### To upright the watercraft:


 Remove the clip from the engine shut-off switch.

## **Operation**

(2) Swim to the rear of the watercraft. Turn the watercraft over clockwise by pulling on the ride plate with your left hand while pushing down on the gunwale with your right hand or foot.

If the port (left) side of the capsized watercraft is tilting up, push down on the gunwale so that the port (left) side is down before turning the watercraft clockwise. NOTICE: Do not turn the watercraft over counterclockwise, otherwise water can enter the engine, which can result in severe damage.

[ECJ00541]



(3) Start the engine and operate the water-craft at planing speed to drain the bilge water from the engine compartment. (See page 52 for information on draining the bilge water. If the engine does not start, see "Towing the watercraft" on page 96 or "Submerged watercraft" on

page 97.) NOTICE: Do not run the engine at full throttle for at least 1 minute after the engine has been restarted. Bilge water in the engine compartment can splash into the engine, which can result in severe damage.

[ECJ00553]

FJU37521

# **Beaching and docking the watercraft**To beach the watercraft:

- Make sure that there are no boats, swimmers, or obstacles near the beach.
- (2) Release the throttle lever to reduce speed about 130 m (430 ft) before you reach the intended beaching area.
- (3) Slowly approach the beach and stop the engine just before reaching land. WARNING! You need throttle to steer. Shutting the engine off can cause you to hit an obstacle you are attempting to avoid. A collision could result in severe injury or death. [ENALOGE IN NOTICE: Never run the engine in water that is less than 60 cm (2 ft) deep from the bottom of the watercraft, otherwise pebbles or sand could be sucked into the jet intake, causing impeller damage and engine overheating. [ECJ00472]
- (4) Get off the watercraft and pull it up on the beach.

#### To dock the watercraft:

- Make sure that there are no boats, swimmers, or obstacles near the dock.
- (2) Release the throttle lever to reduce speed about 130 m (430 ft) away from the dock.
- (3) Slowly approach the dock and stop the engine just before coming alongside it. WARNING! You need throttle to steer. Shutting the engine off can cause you to hit an obstacle you are attempting

# to avoid. A collision could result in severe injury or death. [EWJ00601]

(4) Come alongside the dock and get off the watercraft.

EJU37193

#### Operating in weeded areas

Always avoid using your watercraft in areas where weed growth is thick. If operating in weeded areas is unavoidable, alternately squeeze the throttle lever and relax your grip on the throttle lever to vary the engine speed. Weeds tend to become clogged more when operating at a steady speed and at trolling speed. If weeds may have clogged the intake area, clean the jet intake. (See page 92 for information on the jet intake.)

F.II I4024

# After removing the watercraft from the water

FCJ01310

#### **NOTICE**

Do not run the engine over 4000 r/min on land. Also, do not run the engine for more than 15 seconds without supplying water, otherwise the engine could overheat.

After operating and removing the watercraft from the water, promptly discharge the remaining water from the cooling water passages.

To discharge water from the cooling water passages:

- (1) Make sure that the area around the watercraft is clear, and then start the engine.
- (2) Discharge the remaining water out of the cooling water passages by alternately squeezing and releasing the throttle lever quickly for 10 to 15 seconds.
- (3) Stop the engine.

EJU37145

## Post-operation care

EWJ00330

## **WARNING**

Always place the watercraft upright in a horizontal position when storing it, otherwise fuel could leak out into the engine or engine compartment, which could create a fire hazard.

After using the watercraft, always take it out of the water, clean it, and store it. Leaving the watercraft in the water for extended periods will accelerate the rate of normal deterioration of the jet pump and hull. Marine organisms and corrosion are some of the conditions that can shorten the life of many watercraft components.

EJU37562

Flushing the cooling water passages

#### **NOTICE**

Do not run the engine over 4000 r/min on land. Also, do not run the engine for more than 15 seconds without supplying water, otherwise the engine could overheat.


Flush the cooling water passages to prevent them from clogging with salt, sand, or dirt.

- (1) Place the watercraft in a horizontal position.
- (2) Remove the seats and watertight storage compartment. (See page 41 for seat removal and installation procedures and page 46 for information on the watertight storage compartment.)

(3) Connect the garden hose adapter to a garden hose.




- 1 Garden hose adapter
- (4) Loosen the flushing hose connector cap and remove it. Insert the garden hose adapter into the flushing hose connector and turn it until it is securely connected.



- 1 Garden hose adapter
- 2 Flushing hose connector cap
- 3 Flushing hose connector
- (5) Connect the garden hose to a water tap.
- (6) Make sure that the area around the watercraft is clear, and then start the engine. Immediately after the engine starts, fully turn the water supply on so that water

flows out continually from the jet thrust nozzle.



- (7) Run the engine at idling speed for about 3 minutes watching the engine condition. If the engine stops while flushing, turn the water supply off immediately and perform the procedure again from step 6. NOTICE: Do not supply water to the cooling water passages when the engine is not running. The water could flow back through the muffler into the engine, causing severe engine damage. [ECJ00122]
- (8) Turn the water supply off.
- (9) Discharge the remaining water out of the cooling water passages by alternately squeezing and releasing the throttle lever quickly for 10 to 15 seconds.
- (10) Stop the engine.
- (11) Remove the garden hose adapter, and then securely install the flushing hose connector cap by tightening it until it stops.
- (12) Securely install the watertight storage compartment and seats in their original positions.

## EJU33735

#### Cleaning the watercraft

- (1) Remove the seats. (See page 41 for seat removal and installation procedures.)
- (2) Rinse the engine and engine compartment with a small amount of water.

NOTICE: Do not use high-pressure water when rinsing the engine or engine compartment as severe engine damage could result. [ECJ00571]

- (3) Drain the water from the engine compartment. (See page 52 for information on draining the bilge water.)
- (4) Wipe the engine and engine compartment with a dry cloth.
- (5) Wash down the hull, deck, and jet pump with fresh water.
- (6) Wipe the hull, deck, and jet pump with a dry cloth.
- (7) Wipe all vinyl and rubber components, such as the seats and engine compartment seals, with a vinyl protectant.
- (8) To minimize corrosion, spray metallic parts of the hull, deck, and engine with a rust inhibitor.
- (9) Allow the engine compartment to air dry completely before installing the seats.
- (10) Securely install the seats in their original positions.

EJU33686

#### **Battery care**

If the watercraft will not be used for more than a month, remove the battery from the watercraft, check it, and then store it in a cool, dry place.

EWJ00791

## **WARNING**

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. Electrolyte contains sulfuric acid. Avoid contact with skin, eyes, or clothing.

#### **Antidotes**

External: Flush with water.

Internal: Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call a physician immediately.


Eyes: Flush with water for 15 minutes and get prompt medical attention.

Batteries produce explosive gases. Keep sparks, flames, cigarettes, etc., well away. If using or charging the battery in an enclosed space, make sure that it is well ventilated. Always shield your eyes when working near batteries.

Keep out of the reach of children.

#### To remove the battery:

- (1) Disconnect the negative (-) battery lead.
- (2) Disconnect the positive (+) battery lead.
- Disconnect the breather hose.
- (4) Unhook the battery bands, and then remove the battery from the watercraft.



- 1 Negative (-) battery terminal: Black lead
- 2 Battery band
- 3 Positive (+) battery terminal: Red lead
- 4 Breather hose


#### Checking the battery

- Make sure that the battery case is not damaged.
- Make sure that the battery terminals are not corroded or damaged.
- Make sure that the breather hose is not clogged or damaged.

#### Checking the electrolyte level

Make sure that the electrolyte level is between the maximum and minimum level marks.

If the electrolyte level is low, add distilled water to raise it to the specified level. *NOTICE:* Use only distilled water for replenishing the battery, otherwise battery life could be shortened. [ECJ00241]




- 1 Maximum level mark
- 2 Minimum level mark

If distilled water was added, check the battery voltage.

It is recommended to have a Yamaha dealer check the battery voltage and charge the battery. If you charge the battery yourself, be sure to read and follow the instructions provided with the battery tester and charger you use. **NOTICE:** Do not attempt to charge a battery hastily. Battery life could be shortened. [ECJ00251]

#### Checking the battery bands

Make sure that the battery bands are not damaged.




1 Battery band

#### To store the battery:

- (1) Clean the battery case using fresh water.
- (2) If the battery terminals are dirty or corroded, clean them using a wire brush.

obstructed, or not connected properly. [EWJ00451]

(5) Make sure that the battery is securely held in place.



- 1 Battery terminal
- (3) Apply Yamaha Marine Grease or Yamaha Grease A to the battery terminals.

Recommended water-resistant grease: Yamaha Marine Grease/Yamaha Grease A

(4) Store the battery in a cool, dry place. NOTICE: Storing the battery in an uncharged condition can cause permanent battery damage. Check the battery periodically. [ECJO0102]

#### To install the battery:

- (1) Place the battery in the battery compartment and hook the battery bands onto the holders.
- (2) Connect the positive (+) battery lead (red) to the positive (+) battery terminal. **NOTICE:** Reversal of the battery leads will damage the electrical parts. [ECJO0261]
- (3) Connect the negative (–) battery lead (black) to the negative (–) battery terminal.
- (4) Connect the breather hose to the battery. WARNING! Fire or explosion could result if the breather hose is damaged,

EJU33492

## Long-term storage

EWJ00330

## **WARNING**

Always place the watercraft upright in a horizontal position when storing it, otherwise fuel could leak out into the engine or engine compartment, which could create a fire hazard.

Storage for long periods of time, such as winter storage, requires preventive maintenance to ensure against deterioration. It is advisable to have the watercraft serviced by a Yamaha dealer prior to storage.

However, the following procedures can be performed easily by the owner.

EJU40762

#### Cleaning

 Flush the cooling water passages. (See page 78 for information on flushing the cooling water passages.)

#### TIP:

If you will be storing the watercraft for a prolonged period, such as winter storage, top off the fuel tank with fresh gasoline and add fuel stabilizer and conditioner to the fuel tank according to the manufacturer's instruction before starting the engine.

(2) Clean the watercraft. (See page 79 for information on cleaning the watercraft.)
Wax the hull with a non-abrasive wax.

EJU41260


#### Lubrication

Use a suitable marine grease applicator to pressure-lubricate the cables and purge out any moisture between the inner and outer cables.


To keep moving parts sliding or rotating smoothly, lubricate them with water-resistant grease.

Recommended water-resistant grease: Yamaha Marine Grease/Yamaha Grease A

• Throttle cable (throttle lever end)



 Steering cable (jet thrust nozzle end) and Q.S.T.S. rod (jet thrust nozzle end)



Shift cable (reverse gate end)



EJU40811

### Rustproofing

Spray metallic parts of the hull, deck, and engine with a rust inhibitor.

Have a Yamaha dealer rustproof the internal engine components.

## **Maintenance**

FJU33768

#### Maintenance

Periodic checks and lubrication will keep your watercraft in the safest and most efficient condition possible. Therefore, make sure to carry out the periodic maintenance. Safety is an obligation of the watercraft owner. Proper maintenance must be carried out to keep the exhaust emission and sound levels within the regulated limits. The most important points of watercraft inspection and lubrication are explained on the following pages.

See a Yamaha dealer for genuine Yamaha replacement parts and optional accessories designed for your watercraft.

Remember, failures that are the result of the installation of parts or accessories which are not qualitatively equivalent to genuine Yamaha parts are not covered by the limited warranty.

Maintenance, replacement, or repair of the emission control devices and system may be performed by any marine SI engine repair establishment or individual. Warranty repair, however, must be performed at an authorized Yamaha marine dealership.

EWJ00311


## **WARNING**

Be sure to turn off the engine when you perform maintenance unless otherwise specified. If you are not familiar with machine servicing, this work should be done by a Yamaha dealer or other qualified mechanic.

EJU33802

#### **Tool kit**

A tool kit is included with this watercraft. Place the tool kit in a waterproof bag and always carry it with you whenever you use the watercraft.



- 1 Tool bag
- 2 Screwdriver
- 3 Garden hose adapter
- 4 10/12 mm box wrench
- 5 Pliers
- 6 Open-end wrench


EJU42020

# Removing and installing the engine cover

The engine cover is removable.


To remove the engine cover:

- (1) Remove the seats. (See page 41 for seat removal and installation procedures.)
- (2) Remove the engine cover screws.



1 Engine cover screw


(3) Lift up the engine cover to remove it.



1 Engine cover

## To install the engine cover:

(1) Place the engine cover in its original position, and then push it down.



(2) Install the engine cover screws, and then tighten them to the specified torque.

Tightening torque: Engine cover screw: 4.5 Nm (0.46 kgf-m, 3.3 ft-lb)

(3) Securely install the seats in their original positions.

## **Maintenance**

EJU37062

#### Periodic maintenance chart

The periodic maintenance chart gives general guidelines for periodic maintenance. Have a Yamaha dealer perform the checks in the following chart. However, maintenance may need to be performed more frequently depending on your operating conditions. If you have any questions, consult a Yamaha dealer.

This "O" mark indicates items to be checked and serviced by a Yamaha dealer.

		Initial		Thereaft	er every				
Item	Operation	10 hours	50 hours		100 hours	200 hours	Page		
			6 months	12 months	12 months	24 months			
Spark plugs	Check, clean, replace	$\circ$			$\circ$				
Lubrication points	Lubricate				$\circ$		1		
Internal engine components	Spray lubricant			0			1		
Intermediate hous- ing	Lubricate	0			0				
Fuel system	Check				$\circ$				
Fuel tank	Check, clean				0		1		
Engine idling speed	Check, adjust				0				
Throttle shaft	Check				$\circ$		1		
Water inlet strain- er	Check, clean				0		1		
Bilge strainer	Clean				$\circ$		1		
Electric bilge pump strainer	Clean				0				
Impeller	Check				$\circ$				
Jet thrust nozzle angle	Check, adjust				0				
Steering master	Check, adjust	0			0				
Q.S.T.S. mecha- nism	Check, adjust	0			0		1		
Shift cable and reverse gate	Check, adjust				0				
Throttle cable	Check	0			0		_		
Stern drain plugs	Check, replace				0				
Battery	Check, charge				0		_		
Rubber coupling	Check					0			

		Initial	Thereafter every				
Item	Operation	10 hours	50 hours 100 200 hours hours		200 hours	Page	
			6 months	12 months	12 months	24 months	
Engine mount	Check					0	-
Nuts and bolts	Check	0			0		_
Air filter element	Check				0		_
Engine oil	Replace	0		0			87
Oil filter	Replace				0		87
Valve clearance	Check, adjust					0	_

EJU36942

### Engine oil and oil filter

EWJ00340



Engine oil is extremely hot immediately after the engine is turned off. Coming in contact with or getting any engine oil on your clothes could result in burns.

ECJ00991

## NOTICE

Do not run the engine with too much or not enough oil in the engine, otherwise the engine could be damaged.

It is recommended to have a Yamaha dealer change the engine oil and the engine oil filter. However, if you choose to change the oil and filter on your own, consult a Yamaha dealer.

# **Specifications**

Specifications	Spark plug: LFR6A
Watercraft capacity:	Spark plug gap:
Maximum people on board:	0.8–0.9 mm (0.031–0.035 in)
3 person	Battery capacity:
Maximum load capacity:	12 V, 19 Ah
240 kg (530 lb)	Charging system:
Dimensions:	Flywheel magneto
Length:	Drive unit:
3370 mm (132.7 in)	Propulsion system:
Width:	Jet pump
1230 mm (48.4 in)	Jet pump type:
Height:	Axial flow, single stage
1160 mm (45.7 in)	Impeller rotation:
Dry weight:	Counterclockwise
369 kg (813 lb)	Jet thrust nozzle angle:
Performance:	24.0+24.0 °
Maximum output (according to ISO 8665/SAE	Jet thrust nozzle trim angle:
J1228):	-10, -5, 0, 5, 10 °
154.5 kW@7500 r/min	Fuel and oil:
Maximum fuel consumption:	Recommended fuel:
63.7 L/h (16.8 US gal/h, 14.0 lmp.gal/h)	Regular unleaded gasoline
Cruising range at full throttle:	Minimum octane rating (PON):
1.10 hour	86
Trolling speed:	Minimum octane rating (RON):
1250 ±100 r/min	90
Engine:	Recommended engine oil type SAE:
Engine type:	SAE 10W-30, 10W-40, 20W-40, 20W-50
Liquid cooled 4-stroke, DOHC	Recommended engine oil grade API:
Number of cylinders:	API SE,SF,SG,SH,SJ,SL
4	Fuel tank total capacity:
Engine displacement:	70 L (18.5 US gal, 15.4 Imp.gal)
1812 cm <sup>3</sup>	Engine oil quantity with oil filter replacement:
Bore & stroke:	3.1 L (3.28 US qt, 2.73 Imp.qt)
$86.0 \times 78.0 \text{ mm} (3.39 \times 3.07 \text{ in})$	Engine oil quantity without oil filter replacement
Compression ratio:	3.0 L (3.17 US qt, 2.64 Imp.qt)
8.6 : 1	Engine oil total quantity:
Valve clearance-intake (cold):	4.3 L (4.55 US qt, 3.78 Imp.qt)
0.14-0.23 mm (0.0055-0.0091 in)	
Valve clearance-exhaust (cold):	
0.28-0.37 mm (0.0110-0.0146 in)	
Lubrication system:	
Wet sump	

Cooling system: Water Starting system: Electric Ignition system: T.C.I. EJU34561

## **Troubleshooting**

If you have any trouble with your watercraft, use the troubleshooting chart to check for the possible cause.

If you cannot find the cause, consult a Yamaha dealer.

EJU36984

### **Troubleshooting chart**

Confirm the possible cause and remedy, and then refer to the applicable page.

TROUBLE	POSSIBLE CAUSE		REMEDY	PAGE
Engine does not start (Starter motor	Yamaha Se- curity System	Lock mode selected	Select unlock mode	27
does not turn over)	Engine shut- off switch	Clip not in place	Install clip	28
	Fuse	Burned out	Replace fuse and check wiring	93
	Battery	Run down	Recharge	79
		Poor terminal con- nections	Tighten as required	79
		Terminal corroded	Clean or replace	79
	Starter motor	Faulty	Have serviced by Yamaha dealer	_
Engine does not	Throttle lever	Squeezed	Release	28
start (Starter motor turns over)	Fuel	Empty	Refill as soon as possible	49
		Stale or contaminated	Have serviced by Yamaha dealer	_
	Fuel tank	Water or dirt present	Have serviced by Yamaha dealer	_
	Spark plug	Fouled or defective	Have serviced by Yamaha dealer	_
	Spark plug cap	Not connected or loose	Have serviced by Yamaha dealer	_
		Connected to wrong cylinder	Have serviced by Yamaha dealer	_
	Fuel injec- tion system	Fuel pump faulty	Have serviced by Yamaha dealer	_

TROUBLE	POSSIBLE CAUSE		REMEDY	PAGE
Engine runs irregu- larly or stalls	Fuel	Empty	Refill as soon as possible	49
		Stale or contaminated	Have serviced by Yamaha dealer	_
	Fuel tank	Water or dirt present	Have serviced by Yamaha dealer	_
	Spark plug	Fouled or defective	Have serviced by Yamaha dealer	_
		Incorrect heat range	Have serviced by Yamaha dealer	_
		Gap incorrect	Have serviced by Yamaha dealer	_
	Spark plug cap	Not connected or loose	Have serviced by Yamaha dealer	_
		Cracked, torn, or damaged	Have serviced by Yamaha dealer	_
	Electrical wir- ing	Loose connection	Have serviced by Yamaha dealer	_
	Fuel injec- tion system	Faulty or clogged in- jectors	Have serviced by Yamaha dealer	_
Warning light or in- dicator blinks or	Fuel level	Empty	Refill as soon as possible	49
comes on	Oil pressure warning	Oil pressure dropped	Have serviced by Yamaha dealer	38
	Engine over- heated	Jet intake clogged	Clean	92
	Check engine warning	Faulty sensors	Have serviced by Yamaha dealer	39

TROUBLE	POSSIBLE CAUSE		REMEDY	PAGE
Watercraft slow or loses power	Shift lever	Not completely shift- ed into forward posi- tion	Push lever forward until it stops	32
	Watercraft operation mode	Low RPM Mode activated	Deactivate Low RPM Mode	34
	Cavitation	Jet intake clogged	Clean	92
		Impeller damaged or worn	Have serviced by Yamaha dealer	92
	Engine over- heat warning	Engine speed reduction control activated	Clean jet intake and cool engine	39
	Oil pressure warning	Engine speed reduction control activated	Add oil	38
	Spark plug	Fouled or defective	Have serviced by Yamaha dealer	_
		Incorrect heat range	Have serviced by Yamaha dealer	_
		Gap incorrect	Have serviced by Yamaha dealer	_
	Spark plug cap	Not connected or loose	Have serviced by Yamaha dealer	_
	Electrical wir- ing	Loose connection	Have serviced by Yamaha dealer	_
	Fuel	Stale or contaminated	Have serviced by Yamaha dealer	_
	Air filter	Clogged	Have serviced by Yamaha dealer	_
		Oil buildup	Have serviced by Yamaha dealer	_

EJU34623

## **Emergency procedures**

FJU34634

Cleaning the jet intake and impeller

EWJ00782


### **WARNING**

Before attempting to remove weeds or debris from the jet intake or impeller area, shut the engine off and remove the clip from the engine shut-off switch. Severe injury or death could result from coming in contact with the rotating parts of the jet pump.


If weeds or debris gets caught in the jet intake or impeller, cavitation can occur, causing jet thrust to decrease even though engine speed rises. If this condition is allowed to continue, the engine will overheat and may seize. *NOTICE:* If weeds or debris gets caught in the jet intake, do not operate the watercraft above trolling speed until they have been removed. [ECLO00655]

If there is any sign that the jet intake or impeller is clogged with weeds or debris, return to shore and check the intake and impeller. Al-

ways stop the engine before beaching the watercraft.



(1) Place a suitable clean cloth or carpeting underneath the watercraft to protect it from abrasions and scratches. Turn the watercraft on its side as shown. NOTICE: Always turn the watercraft over onto its port (left) side. When turning the watercraft on its side, support the bow so that the handlebars are not bent or damaged. [ECJOOG61]



(2) Remove any weeds or debris from around the jet intake, drive shaft, impeller, jet pump housing, and jet thrust nozzle.

If debris is difficult to remove, consult a Yamaha dealer.

EJU34641

### Jumping the battery

If the watercraft battery has run down, the engine can be started using a 12-volt booster battery and jumper cables.

EJU34663

#### Connecting the jumper cables


EWJ01250

## **WARNING**

To avoid battery explosion and serious damage to the electrical system:

- Do not reverse the polarity of the jumper cables when connecting to the batteries.
- Do not connect the negative (-) jumper cable to the negative (-) terminal of the watercraft battery.
- Do not touch the positive (+) jumper cable to the negative (-) jumper cable.
- Connect the positive (+) jumper cable to the positive (+) battery terminals of both batteries.
- (2) Connect one end of the negative (–) jumper cable to the negative (–) battery terminal of the booster battery.

(3) Connect the other end of the negative (–) jumper cable to an engine hanger.




- 1 Negative (-) jumper cable
- 2 Positive (+) jumper cable
- 3 Booster battery
- 4 Engine hanger
- (4) Start the engine, and then disconnect the jumper cables by reversing the steps above. (See page 28 for information on starting the engine.)

EJU36994

#### Replacing the fuses

If a fuse is blown, replace it with the proper fuse.




- 1 Good fuse
- 2 Blown fuse

## To replace a fuse:


(1) Remove the seats. (See page 41 for seat removal and installation procedures.)

(2) Remove the electrical box cover.




- 1 Electrical box cover
- Loosen the cap on the electrical box and remove it.
- (4) Replace the blown fuse with the spare fuse of the correct amperage by using the fuse puller on the reverse side of the cap. WARNING! Do not use fuses of a different amperage than recommended. Substitution with a fuse that has an improper rating can cause extensive

# electrical system damage and possible fire. [EWJ00802]



- 1 Electrical box
- 2 Spare fuse
- 3 Fuse
- 4 Cap



1 Fuse puller

Fuse amperage:
Battery fuse:
30 A
Main relay drive fuse:
10 A
Electronic throttle valve fuse:
10 A
Security system fuse:
3 A
Main fuse:
20 A


- (5) Securely install the cap by tightening it until it stops.
- (6) Securely install the electrical box cover in its original position.

(7) Securely install the seats in their original positions.

If the fuse immediately blows again, the electrical system may be defective. If this occurs, have a Yamaha dealer service the watercraft.

#### Replacing the bilge pump fuse

If the fuse is blown, replace it with the proper fuse.




- 1 Good fuse
- 2 Blown fuse

#### To replace the fuse:

- Remove the seats and engine cover. (See page 41 for seat removal and installation procedures and page 84 for engine cover removal and installation procedures.)
- (2) Remove the plastic ties that are securing the corrugated tube and bilge pump fuse leads.

#### TIP:

Be careful not to drop the plastic ties into the engine compartment.




- 1 Bilge pump fuse lead
- 2 Plastic tie
- 3 Corrugated tube
- (3) Pull out the bilge pump fuse holder from the rubber cover, and then remove the fuse cover.
- (4) Replace the blown fuse with the spare fuse of the correct amperage. WARNING! Do not use fuses of a different amperage than recommended. Substitution with a fuse that has an improper rating can cause extensive electrical system damage and possible fire.

#### TIP:

If the fuse is difficult to remove, use the fuse puller on the reverse side of the electrical box

cap. (See page 93 for information on the fuse puller.)




- 1 Bilge pump fuse holder
- 2 Fuse cover
- 3 Spare fuse
- 4 Fuse

Fuse amperage: Bilge pump fuse:

3 A

- (5) Securely install the fuse cover, and then fit the bilge pump fuse holder into the rubber cover.
- (6) Secure the bilge pump fuse leads and corrugated tube with the plastic ties.



- 1 Bilge pump fuse lead
- 2 Plastic tie
- 3 Corrugated tube
- 4 Rubber cover
- (7) Securely install the engine cover and seats in their original positions.

If the fuse immediately blows again, the electrical system may be defective. If this occurs, have a Yamaha dealer service the watercraft.

## **Towing the watercraft**

EWJ008

## **WARNING**


- The operator of the towing boat must keep speed to a minimum and avoid traffic or obstacles which could be a hazard to the operator on the watercraft.
- The towline should be long enough so that the watercraft will not collide with the towing boat when slowing down.

If the watercraft becomes inoperative in the water, it can be towed to shore.

#### To tow the watercraft:

Use a towline that is three times the combined length of the towing boat and the watercraft.

 Securely attach the towline to the bow eye of the watercraft being towed.



- 1 Bow eye
- (2) Sit astride the seat and hold on to the handlebars in order to balance the watercraft. NOTICE: The bow must be kept up out of the water during towing, otherwise water could flood the engine compartment or water could flow back into the engine, causing severe engine damage. [ECJ01330]

Tow the watercraft at 8 km/h (5 mph) or less. *NOTICE:* Tow the watercraft at 8 km/h (5 mph) or less, otherwise water could flood the engine compartment or water could flow back into the engine, causing severe engine damage. [ECJ01321]

EJU36155

#### Submerged watercraft

If the watercraft is submerged or flooded with water, drain the bilge water from the engine compartment. Then, have a Yamaha dealer service the watercraft as soon as possible.

#### If the watercraft was submerged:

- (1) Remove the watercraft from the water and drain the water from the storage compartments. (See page 44 for information on draining the storage compartments.)
- (2) Drain the bilge water from the engine compartment. (See page 52 for information on draining the bilge water.)
- (3) Have the watercraft serviced by a Yamaha dealer as soon as possible. NOTICE: Be sure to have a Yamaha dealer inspect the watercraft. Otherwise, serious engine damage could result. [ECJ00791]

# Index

A	Engine serial number	
After removing the watercraft from	Engine shut-off cord (lanyard) check	
the water77		
В	Engine stop switch	. 28
Battery care79		
Battery checks59	Enjoy your watercraft responsibly	. 20
Battery, jumping93		
Beaching and docking the watercraft 76	6 <b>F</b>	
Beverage holder46	Fire extinguisher check	. 64
Bilge pump fuse, replacing95	Fire extinguisher holder and cover	. 47
Bilge water check59	Fire extinguisher holder, cover, and	
Bilge water, draining52	band checks	. 64
Bilge water, draining on land 52	2 Flushing the cooling water passages	. 78
Bilge water, draining on water 53		
Boarding alone72	Puel level check	. 58
Boarding and starting off from a dock 75		
Boarding the watercraft71	Fuel level warning	. 38
Boarding with passenger(s)	Puel requirements	. 49
Bow eye43		
Bow storage compartment 44	Fuses, replacing	. 93
Builder's plate2		
C	Getting to know your watercraft	. 66
Capsized watercraft75		
Check engine warning39	Glove compartment	. 45
Cleaning82		
Cleaning the watercraft 79		
Cleat43		
Cooling water pilot outlet check 65		
Cooling water pilot outlets30		. 37
Craft Identification Number (CIN)1		. 64
Cruising limitations 12		
D	Identification numbers	
Dual analog meter unit36		. 37
Dual analog meter unit check65		
E	Jet intake and impeller, cleaning	
Emergency procedures92		
Engine break-in55		. 93
Engine compartment check58		
Engine cover, removing and installing 84		
Engine idling speed check 65		
Engine oil51		
Engine oil and oil filter87		
Engine oil level check59		
Engine oil requirements51		. 68
Engine overheat warning 39		

# Index

Limitations on who may operate	Starting off74
the watercraft11	Starting off from a trailer75
Long-term storage 82	Starting the engine on water 67
Low RPM Mode34	Steering system
Lubrication82	Steering system checks60
M	Stern drain plug checks64
Main components, location of22	Stern eyes43
Maintenance84	Stopping the engine68
Manufactured date label2	Stopping the watercraft70
Model information2	Storage compartment checks 63
0	Storage compartments44
Oil pressure warning 38	Submerged watercraft97
Operating in weeded areas77	Switch checks63
Operating the watercraft68	T
Operating the watercraft in reverse71	Tachometer36
Operating your watercraft66	Telescopic steering system30
Operation requirements	Telescopic steering system checks60
P	Throttle lever29
Periodic maintenance chart86	Throttle lever checks 62
Post-launch checks65	Tool kit84
Post-operation care78	Towing the watercraft96
Pre-launch checks58	Transporting on a trailer54
Pre-operation check points 58	Troubleshooting89
Pre-operation checklist56	Troubleshooting chart89
Primary Identification (PRI-ID) number 1	Turning the watercraft69
Q `	w
Quick Shift Trim System (Q.S.T.S.) 33	Water separator3
Quick Shift Trim System (Q.S.T.S.)	Water separator check 58
checks61	Watercraft characteristics
R	Watercraft control functions
Reboarding grip42	Watercraft operation functions
Reboarding step42	Watercraft operation modes 34
Recommended equipment15	Water-skiing18
Remote control transmitter	Watertight storage compartment
Remote control transmitter check 62	Υ
Reverse system 32	Yamaha Security System27
Reverse system checks	Yamaha Security System settings 27
Riding position	
Rustproofing	
S	
Safe boating rules19	
Safety equipment check64	

 Seats
 41

 Speedometer
 36

 Start switch
 28

